

LED Light Up Basketball Rim Light CPBB200CL1ST

# **READ CAREFULLY AND KEEP THIS CARD**

### General Warnings

Do not use in the rain, sleet or snow. Keep away from water and extreme temperatures.
Do not allow batteries to get wet, or dispose of batteries with regular household trash.

#### **Rim Light Battery Installation**

- Undo the 2 clasps on the rim lights' attached battery compartment, and open the compartment.
- Install 3 AA-sized Alkaline batteries, following the polarity (+/-) diagram. Do not mix old and new batteries, or mix different brands or types of battery.
- 3. Close the compartment, and lock the 2 clasps.

### **Rim Light Installation**

- 1. Install batteries according to the instructions above.
- Mount the battery pack to your backboard using the included 3M<sup>™</sup> adhesive hook-and-loop fastener.
  - Peel off one side's adhesive, stick on the battery pack. Press +hold for 1 min.
  - Peel off other side's adhesive, stick on desired location. Press + hold for 1 min.
- Secure the lights to the rim by wrapping the included hook-and-loop fastener strips in tight circles around.

### Using the Rim Lights

- · Press the button on the outside of the battery pack to turn the rim lights ON.
- Press the button additional times to flip through the different modes, and to turn the lights OFF.
- The rim lights can also be controlled with the included remote control. See below for details.

## Using the Rim Lights Remote Control

- 1. Set up and install the rim lights according to the above instructions.
- 2. Remove the plastic tab sticking out of the bottom of the remote control.
- 3. Press the remote control buttons to turn the rim lights ON/OFF, change colors, and set an automatic shutoff timer.





**Remove plastic tab** 

#### 90-Day Limited Warranty

Territory: United States/Canada

#### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

#### To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com
- · Select the brand and model of your device
- · Select "Service Request" and fill out the form to begin your inquiry
- · Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

#### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, NOIRECT, SPECIAL, PUNITVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR. THE WARRANTY SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR. THE WARRANT SHALL NOT EXCEED THE PROCHASE PRICE OF THE PRODUCT SOLD BY DISTIBUTOR. THE WARRANT SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERBABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China v1.09-2021