User Manual
AR88GLXY

(Fold Inward) – – – – ▶   **(Back Cover)**   **(Front Cover)**

Compliance Information

READ CAREFULLY AND SAVE THIS MANUAL FOR FUTURE REFERENCE
FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Rating Label Definitions

⎓ Direct current symbol.

🗑 This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

BC This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

🔵 Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Southern Telecom is under license.

RECYCLE Li-ion 1-800-822-8837

Warranty Information

ART+SOUND™

ART+SOUND™

Instruction Manual
Galaxy Wireless Speaker
AR88GLXY

Before You Begin...

Customer Support
For any questions or problems with your product, please visit our website at **SouthernTelecom.com** and click on **Product Support**.

⚠️ **Caution**
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.
• **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
• Do not disassemble, modify, or repair the device.
• Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
• Do not submerge in water.
• Low power may cause poor Bluetooth connection or sound distortion.
• Do not overcharge battery.
• If using with a USB adapter, make sure the adapter is not damaged.
• Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

In the Box
• AR88GLXY - **Wireless Speaker** (x1)
• USB Charging Cable (x1)
• User Manual (x1)

Location of Controls

[+] [–] Button
(Press) Skip Tracks
(Press + Hold) Adjust Volume

USB Charging Port
Charging LED Indicator

Bluetooth LED Indicator

Charging   Off · On

(Back of Speaker)

[Power] Switch
Power ON/OFF

[◎] Button
(Press) Pause/resume playback

Getting Started

Charging the Speaker
Attach the small connector of the supplied USB charging cable to the USB charging port on speaker. Attach the large connector to the USB port on a computer, a USB charging device, or a **5V USB adapter** *(not included)* and plug into a wall socket.

The charging LED indicator will **turn RED** while charging and turn off when fully charged. When low on power, a tone will be heard, indicating that the speaker should be charged.

Power ON/OFF
• Slide the **[Power]** switch to power the speaker ON/OFF.
• When powered ON, the speaker will automatically reconnect to the device it was most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled.

Bluetooth Pairing
1. Power the speaker ON. A tone will be heard and the LED indicator will **quickly flash BLUE.**
2. Set your mobile device to search for Bluetooth devices. When it appears, select **AR88GLXY** from the list of found devices.
3. Once successfully paired, a tone will be heard and the LED indicator will **slowly flash BLUE.**

Pair to Bluetooth to listen wire-free!

Playing Music
To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device. For more on pairing the speaker to your device, please consult the **Bluetooth Pairing** section.

Once paired, you can control media playback and volume adjustment with the controls on the speaker, or on your paired device.

Controlling Playback & Volume
• Press the **[◎]** button to pause/resume media playback.
• Press the **[+]** and **[–]** buttons to skip tracks.
• Press and hold the **[+]** and **[–]** buttons to adjust volume.