(Fold Inward) — — — ▶

(Back Cover)

(Front Cover)

Wireless Charging Compatibility

AR1073 is compatible Qi-enabled devices, such as:

iPhone XS Max / XS / XR / 8 / 8 Plus / X, Asus Padfone S, Blackberry Z30 (Verizon), iPhone XS Max / XS / XR / 8 / 8 Plus / X, Asus Padfone S, Blackberry Z30 (Verizon), Blackberry Classic, Cat Catphone S50, DeWalf MIL810G, Google Pixel 3 XL, Google P

Please check your mobile device's user manual or documentation to see if it is compatible with the Qi charging standard. This item is NOT compatible with AirFuel/PMA charging standards.

Rating Label Definitions

=== Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

(BC) This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

This symbol represents FCC Declaration of Conformity and compliance.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.

Compliance Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or mor of the following measures:

- neones to repose the leceiving alternation.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technican for help.

This product complies with the requirements for Part 18 of the FCC Rules, Although this product

complies with FCC, it may interfere with other devices. If this product is found to interfere with another device, separate the other device and this product. tadiation Exposure Information he device has been evaluated to meet general RF exposure requirement. The device can be used in portable xposure condition without restriction.

WARNING Li-lon Battery Inside
This product is fitted with a Li-lon battery, Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F),



Location of Controls

Warranty Information

90-day Limited Warranty Territory: United States/Canada

LIMITED WARRANTYTO ORIGINAL CONSUMER
This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

Visit our website at www.southeritelecom.com
 Click on Product Support
 Select the Brand of your device
 Select Service Request and fill out the form to begin your inquiry

returned to the authorized service center for repair must be suitably packaged.

NO WARRANTES, WHETHER EXPERSES ON BIMELD INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE. SHALL APPL. DISTRIBUTION EFFUNDED SIZED SIZED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PROPULE THALL BE BUNDING ON DISTRIBUTION. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS OR DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR OR ITS MANUFACTURES BE LUBBEL FOR ANY NUTURED TO, REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR OR ITS MANUFACTURES BE LUBBEL FOR ANY NUTURED TO, DAMAGES FOR THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURES BE LUBBEL FOR ANY NOTIONAL PRICE FOR ANY NOTIONAL PRICE OF THE CONSUMER. IN OUR CONSUMER, IN OUR CONSUMER OF THE PRODUCT OF THE PR

v1. 09-2020

Getting Started

ART+SOUND

ORB BEATS

LED Wireless Speaker and Qi Charger



Instruction Manual AR1073

Before You Begin...

READ CAREFULLY AND KEEP THIS MANUAL

Customer Support For any questions or problems with your product, please visit our website at SouthernTelecom.com and click on Product Support.

To ensure safe and proper use, read all safety information before using the device. Only use with To ensure safe and proper use, read all safety information before using the device. Only use with manufacture-approved batteries, chargers, accessories, and supplies.

• THIS DEVICE IS NOT A TOY, keep away from children and pets.

• Do not disassemble, modify, or repair the device.

• Do not submerge in water.

• Do not submerge in water.

• Low power may cause poor Bluetooth connection or sound distortion.

• Do not overcharge battery.

• If using with a USB adapter, make sure the adapter is not damaged.

• Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or

- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders,
- etc.

 Do NOT place any metal object onto the charging pad.

 Magnetic strip cards, including credit cards, phone cards, identification cards and boarding passes may be damaged by the magnetic field if placed on or near this device.

 Do not place this device on or near a microwave or similar appliance.

 The speaker contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

- In the Box • AR1073 - Wireless Speaker (x1)
- USB Charging Cable (x1)
 User Manual (x1)

Wireless Charging Pad-[:: Button: Front View Adiust night light brightness [**台**] Button: Side Enable/disable Bluetooth View [旬] Button: lights ON/OFF 0 Charging Port Speaker Wireless ΙĖD Charging Indicator LED Indicator

Charging the Speaker

Plug the micro-USB connector (smaller) of the included charging cable into the micro-USB charging port on the side of the speaker. Plug the USB connector (larger) into a USB power source, or into a **5V USB adapter** (not included) and plug

The speaker LED indicator will turn RED while charging and turn OFF when fully charged. When the speaker is low on power, a tone will be heard indicating that it

Powering ON/OFF

- Press the [🖒] button on the side of the speaker to power ON and OFF. When powered ON, the speaker will enter Bluetooth
- pairing mode, and may automatically re-pair to any available previously-paired device nearby.

Playing Music

To listen to music or audio on the speaker you must be paired to an audio device via Bluetooth® wireless. If you are pairing for the first time, see the **Bluetooth** Pairing section of this manual.

When connected, all volume & playback adjustment will be controlled with your

Bluetooth Pairing

- 1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode. The speaker LED indicator will quickly flash BLUE.

 2. Set your mobile device to search for Bluetooth devices. When the list appears,
- select AR1073 from the found devices
- 3. After a successful pairing, a tone will be heard, and the speaker LED indicator will slowly flash BLUE.

- Using the LED Lights
 Press the [Ø] button to turn the color-changing lights ON or OFF.
- Press the [.] button to adjust night light brightness

Place your device face up in the center of the wireless charging pad, facing up. The wireless charging LED indicator will turn BLUE to indicate that your device is charging.

The wireless charging pad. This can damage the object or charging pad. This can be compared to the wireless charging.



NOTE: This charging pad is compatible with the Qi charging standard.This item is NOT compatible with AirFuel/PMA charging standards. Please check your mobile device's user manual or documentation to see if it is compatible.



