(Fold Inward) — — — **▶**

(Back Cover)

ART+SOUND

(Front Cover)

Compliance Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Rote: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference at radio communications. However, there is no guarantee that interference will not occur in a particular installation, If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Recrient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

**Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, **Connect the equipment and receiver is expensed and the provided and the prov

This device comples with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

exposure condition without restriction.

WARNING Li-ion Bartary Inside

This product is fitted with a Li-ion battery, Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original urchaser against defects in materials and workmanship ("Warranty") as follows:

- To obtain warranty service:

 Visit our customer support portal: www.customersupport123.com
 Select the brand and model of your device
 Select "Service Request" and fill out the form to begin your inquiry
 Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, afters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR INFLED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLED WARRANTIES OF MERCHANTIES, WHETHER EXPRESS OR INFLED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THANTHOSE EXPRESSIV DESCRIBED ABOVE. SHALL APPLY, DISTRIBUTOR FURTHER DISCLAIMS, ALL WARRANTIES, AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE. AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR ITS MANUFACTURERS BE LIBLE FOR HAY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSCIUNCIAL DAMAGES ISUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SANIOS, DEAT OR RECORDED AUSSED BY THE USE, INSUSE OR INNERLITY TO USE TO SEE THE PURPOSE OF THE PURPO

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of

v1. 01-2021

Getting Started

ART+SOUND



Instruction Manual

LUMINA Wireless Lantern LED Speaker

Before You Begin...

READ CAREFULLY AND KEEP THIS MANUAL

Customer Support For any questions or problems with your product, please visit our website at

customerservice123.com

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

• THIS DEVICE IS NOT A TOY, keep away from children and pets.

- Do not disassemble, modify, or repair the device.
 Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet


. Do not submerge in water.

- Low power may cause poor Bluetooth connection or sound distortion.
 Do not overcharge battery.
 If using with a USB adapter, make sure the adapter is not damaged.

- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- The speaker contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of

- In the Box
 AR1078 Wireless Speaker (x1)
- Micro-USB Charging Cable (x1)User Manual (x1)

Location of Controls



Charging the Speaker

Plug the small connector of the included micro-USB charging cable into the charging port on the speaker. Plug the large connector into a USB power source such as the USB port on a computer, or into a **5V USB adapter** (not included) and

The LED indicator will turn RED while charging and turn OFF when fully charged. When the speaker is low on power, a tone will be heard indicating that it needs to

Powering ON/OFF

- Move the [Power] switch to power ON and OFF.
 When powered ON, the speaker may automatically re-pair to a previously-paired device

- Bluetooth Pairing
 1. Power the speaker ON. A tone will be heard and the speaker will enter
- Bluetooth pairing mode.

 2. Go to your device's Bluetooth Settings and set your device to search for new Bluetooth devices. When it appears, select AR1078 from the list of found devices.
- 3. After a successful pairing, a tone will be heard and you will be able to play music on the speaker.

In Bluetooth mode, playback & volume can be controlled by the buttons on the speaaker or your paired device.

Using the AUX Input

Insert one end of a 3.5 mm auxiliary cable (not included) into the 3.5 mm AUX port on the speaker. Insert the other end into the headphone jack or 3.5 mm AUX output port on your media-playing device.

The speaker will automatically enter AUX mode.

In AUX mode, all playback will be controlled by your connected device.