# **User Manual AR3038**

# **Compliance Information**

### FCC Information

This device complies with Part 15 of the FCC Rules

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

   Connect the equipment into an outlet on a circuit different from that to
- which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### Rating Label Definitions

Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



 $\begin{array}{c} \\ BC \\ \end{array} \label{eq:BC} \begin{picture}(100,00) \put(0,0){$B$} \put(0,0){$C$} \put$ Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth\* technology. The Bluetooth\* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

# Warranty Information

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

- To obtain warranty service

  Visit our website at www.s

  Click on Product Support

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLEO WARRANTES OF MERCHANTABILITY OR ITINESS FOR A PRIFICULAR PURPOS, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY, DESTRIBUTOR FURTHER DISCLAMS ALL WARRANTIS FOR A PRIFICAL PROPERTY OF A PLANT OF

untries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so nor exclusions may not agony fot you. This warranty gives you specific (sigal rights, and you may have other rights that vary from state to state or to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

## Printed in China Designed in USA v2. 04-2019

# **ART+SOUND**

# AVANT

Wireless Soundbar Speaker



**Instruction Manual** AR3038

# Before You Begin...

# **A** CAUTION

# · READ CAREFULLY AND KEEP THIS MANUAL

- ·THIS IS NOT A TOY, Please keep away from children and pets
- · Keep away from water and extreme temperatures.
- · Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge the battery.
- Do not open this product or attempt to repair the unit yourself should it not be working.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- · Do not submerge in water

## WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).




## Questions & Customer Support

For questions, troubleshooting or any other assistance, please visit our website at SouthernTelecom.com and click on Product Support.



- AR3038 Wireless Speaker (x1)
- USB Charging Cable (x1)
- Instruction Manual (x1)

# **Location of Controls**



## Charging the Speaker

Plug the small connector of the USB cable into the USB charging port on the back of the speaker. Plug the other end into the USB port on your computer, a USB charging device, or a **5V USB charging adapter** (not included) and plug into a wall socket. The LED indicator will turn RED while charging and turn off when fully charged. On low power, a tone will be periodically heard, indicating that the speaker should be charged.

**Getting Started** 

## Using the Speaker

## Make sure that the speaker has been charged.

- Flip the [Power] switch to the ON position. A tone will be heard and the speaker will enter Bluetooth pairing mode. The speaker will automatically re-pair to any nearby, previously-paired device.
- Flip the [Power] switch to the OFF position to power OFF.
- To listen to music on your speaker make sure it is paired to a Bluetooth-enabled device or connected via 3.5 mm AUX input. Playback and volume adjustment is controlled with the paired or connected device.

## Bluetooth Pairing (Wireless)

- 1. Power the speaker ON. A tone will be heard and the LED indicator will turn RED.
- 2. Set your mobile device to search for Bluetooth devices. When it appears, select AR3038 from the list of found devices.
- 3. After a successful pairing, a tone will be heard and the Bluetooth LED indicator will turn GREEN

## Using the AUX Input (Wired)

Insert one connector of a 3.5 mm auxiliary audio cable (not included) into the 3.5 mm AUX input on the back of the speaker. Insert the other connector into the audio output jack of your media-playing device. The LED indicator will turn RED while in use.