

Compliance Information

READ CAREFULLY AND KEEP THIS MANUAL

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Rating Label Definitions

— — Direct current symbol.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Southern Telecom is under license.

ART+SOUND™

ART+SOUND™



Wireless Floating Speaker

Instruction Manual

AR4083AXE

Before You Begin...

⚠ CAUTION

- **READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE**
- **THIS IS NOT A TOY, Please keep away from children and pets**
- Keep away from water and extreme temperatures
- Low power may cause poor Bluetooth connection or sound distortion
- Do not overcharge the battery
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- Do not open this product or attempt to repair the unit yourself should it not be working.
- Only use the supplied power cable to charge this device.
- If charging this device with a power adapter, make sure it is a 5V/1A adapter and is not damaged or defective.

🖨 Questions & Customer Support

For questions, troubleshooting or any other assistance, please visit our website at **SouthernTelecom.com** and click on **Product Support**.


📦 In the Box

- AR4083AXE - Wireless Speaker (x1)
- USB Cable (x1)
- Suction Cup (x1)
- Instruction Manual (x1)

All product names, trademarks, and registered trademarks are property of their respective owners.
All company, product, and service names used in this document are for identification purposes only.
Use of these names, trademarks, and brands does not imply endorsement.

Printed in China
Designed in USA
v1.01-2019

Location of Controls




Getting Started

⚡ Charging the Speaker

Undo the rubber protective seal and insert the small connector of the supplied USB cable into the USB charging port. Insert the large connector into a USB power source such as a computer or a **5V/1A USB adapter (not included)** and plug into a wall socket.

While charging, a LED indicator under the on-board controls will **turn RED**. When fully charged the LED indicator will turn off.



🔌 Powering ON/OFF

- Press and hold the [P] button. A tone will be heard and the speaker will enter Bluetooth pairing mode, will automatically re-connect to any nearby, previously-paired devices that have Bluetooth enabled.
- Press and hold the [P] button again to turn the speaker OFF.

📶 Bluetooth Pairing

1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **FINDYOURMAGIC** from the list of found devices.
3. After a moment, a tone will be heard indicating that the pairing was successful.

🎵 Playing Music

To listen to music on the speaker, you must be paired to a Bluetooth-enabled device (see **Bluetooth Pairing** section of this user manual). Once paired, audio playback and volume can be adjusted via the controls on the speaker or your paired media-playing device.

▶|| Controlling Playback & Volume

- Press the [H] button to pause/resume playback.
- Press the [M] and [M] buttons to skip tracks.
- Press and hold the [M] and [M] buttons to adjust volume.