

## Compliance Information

### FCC Information

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

### FCC Statement

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



### Rating Label Definitions

--- Direct current symbol



This symbol signifies that the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment complies with battery charging which complies with California CEC and energy efficiency.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Southern Telecom is under license.

## Warranty Information

### 90-day Limited Warranty

Territory: United States/Canada

### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

### To obtain warranty service:

- Visit our website at [www.southern telecom.com](http://www.southern telecom.com)
- Click on **Product Support**
- Select the **Brand** of your device
- Select **Service Request** and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

# ART+SOUND™

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China  
Designed in USA  
v1.06-2019

# ART+SOUND™

## Mega Speaker



## Instruction Manual

AR9026

## Before You Begin...

### ⚠ CAUTION

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **READ CAREFULLY AND KEEP THIS MANUAL**
- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- **Do not disassemble, modify, or repair the device.**
- **Do not submerge in water.**
- Low battery may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not allow the USB ports, power jack or other inputs of the device to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

### Questions & Customer Support


For questions or troubleshooting, please visit our website at [SouthernTelecom.com](http://SouthernTelecom.com) and click on **Product Support**.

### In the Box

- AR9026 - **Wireless Speaker** (x1)
- 9V Charging Adapter (x1)
- Microphone (x1)
- Instruction Manual (x1)

## Location of Controls

1. Input LED Indicator
2. Mic Echo Knob
3. [⌘] Button:  
**Press + Hold:** Switch to pairing mode
4. [M] Button: Change input modes
5. [⏮] Button: Skip to previous track
6. Volume Knob
7. [⏭] Button: Skip to next track
8. [⏸] Button: Play/pause music
9. [☼] Button: Cycle through light modes
10. Mic Volume Knob
11. Charging LED Indicator
12. 3.5 mm Auxiliary Input Jack
13. Mic 1 Input Jack
14. Mic 2 Input Jack
15. DC 9V Power Jack
16. [Power] Switch



## Getting Started

### Charging the Speaker

Insert the pin of the supplied 9V charging adapter into the DC 9V power jack on the back of the speaker. Plug the adapter into a wall socket.

The charging LED indicator will **turn RED** while charging and turn OFF when fully charged.

### Powering ON/OFF

- Move the [Power] switch to the ON position to turn speaker ON.
- Move the [Power] switch to the OFF position to turn the speaker OFF.

### Adjusting Speaker & Mic Volume

- Adjust volume of the speaker with the Volume knob.
- Adjust the microphone volume level with the Mic Volume knob.
- Adjust microphone echo effect with the Mic Echo knob.

### Playing Music

To enjoy music wirelessly on your speaker, make sure you are paired to a Bluetooth-enabled device. Once paired, you can control the media playback and volume adjustment with the controls on your paired device or the controls on the speaker. Consult the **Bluetooth Pairing** section below for instruction.

- Quick press the [⏸] button to play/pause media playback.
- Quick press the [⏮] and [⏭] buttons to skip tracks.

### Bluetooth Pairing

1. Power the speaker ON. A tone will be heard and the input LED indicator will quickly **flash BLUE**.
2. Set your Bluetooth-enabled device to search for Bluetooth devices. Select **AR9026** from the list of found devices.
3. Once successfully paired, a tone will be heard and the input LED indicator will **turn solid BLUE**.

### Connecting with a Wired Device

Insert one connector of a 3.5 mm auxiliary cable (*not included*) into the 3.5 mm auxiliary input jack on the back of the speaker. Insert the other connector into the headphone jack or audio output jack of your media-playing device.

Media playback is controlled via the connected device.

### Changing the Input Mode

- Press and hold the [⌘] button to unpair a Bluetooth-paired device and put the speaker into Bluetooth pairing mode.
- Press the [M] button to switch between Bluetooth and auxiliary input modes.

For more information on connecting via Bluetooth, consult the **Bluetooth Pairing** section of this manual. For more information on connecting via 3.5 mm auxiliary input, see the **Connecting to a Wired Device** section of this user manual.

### Using the Lights

- Press the [☼] button on the speaker to enable the lights.
- Continue to press the [☼] button to cycle through the light modes and turn off.

### Using the Mic Inputs

The speaker can support up to two microphones using the 1/4" mic input jacks on the back of the speaker.

Plug the 1/4" connector into the Mic 1 or Mic 2 input jack and adjust the microphone volume using the Mic Volume knob on the top of the speaker.

