

# ART+SOUND™

## Smartphone Tripod with Selfie Light ARAC12

### CAUTION

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.**
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Do not allow the connector to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

### Installing Batteries

1. Remove the battery cover from the back of the selfie light.
2. Insert 2 new AAA-sized Alkaline batteries (*not included*) following the polarity (+/-) diagram in the compartment. Do not mix old and new batteries, or mix different brands or types of battery.
3. Replace the battery cover.

### Setting Up

Pull out the legs of the tripod. Bend the gooseneck selfie light into the desired position. Pull the spring-loaded device holder open, and insert your device. The holder should grip the device securely.

### Using the Selfie Light

Install batteries. Press the [Power] button on the front of the selfie light to turn the light ON/OFF and change the brightness setting.

# ART+SOUND™

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China  
Designed in USA  
v1.08-2020