(Fold Inward) - - - - **▶**

(Back Cover)

(Front Cover)

Using the 3.5 mm AUX Port

- Plug one connector of a 3.5 mm AUX cable (not included) into the 3.5 mm AUX port on the back of the speaker.
- 2. Plug the other connector into the headphone jack or audio output port on your
- 3. The speaker will automatically switch to AUX mode.

In AUX mode, all playback and volume adjustment will be controlled by your connected device.

Using the LED Lights

The speaker's built-in LED lights will automatically power ON when the speaker is powered on.

- When music is not playing, the LED lights will cycle through 7 different colors.

 When music is playing, you can switch LED light modes by 2x pressing the

Note: The LED light mode can only be changed when music is playing.

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment penerates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference various communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Recrieted or relocate the receiving antenna.

- Increase the separation between the equipment and receiver

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

=== Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology

Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

Designed in US Printed in China

ART+SOUND



Instruction Manual

ILLUMA BEAT WIRELESS LED SPEAKER

Before You Begin...

READ CAREFULLY AND KEEP THIS MANUAL

Customer Support For any questions or problems with your product, please visit our website at customersupport123.com

⚠ Caution

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
 Low power may cause poor Bluetooth connection or sound distortion. Do not overcharge battery.
 If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials
- such as liquids, metallic powders, etc.

 This device contains a built-in battery which should not be disposed of with regular household waste. Always follow local laws and regulations in disposing of batteries.

- In the Box
 ARBT52 Wireless Speaker (x1)
- Micro-USB Charging Cable (x1)
- User Manual (x1)

Location of Controls Back

Front $\bigcirc \bigcirc \bigcirc \bigcirc$ 5 6 7

Press: Decrease volume Press + hold: Skip to previous track

2. Microphone

3. O Button: Press: Play/pause, answer/end call 2x Press: Changed LED light mode

Press + hold: Power ON/OFF reject call

4. + Button: Press: Increase volume Press + hold: Skip to next track 5. AUX Input (3.5 mm)

6 LFD Indicator

7. Micro-USB Charging Port

Getting Started

0. 🛖

Charging the Speaker

Plug the small connector of the supplied micro-USB charging cable into the charging port on the speaker.

Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB power adapter (not included).

The LED indicator will turn RED while charging and turn OFF when fully charged.

When the speaker is low on power, a tone will be heard indicating that it needs to be recharged.

Powering ON/OFF

- Press + hold the D button to power ON. A tone will be heard, and the speaker will enter Bluetooth pairing mode. It will automatically re-pair to any nearby, previously-paired device with Bluetooth enabled.
- Press + hold the n button to power OFF.

Playing Music

To play music on the speaker, you must be paired to a Bluetooth device. See the Bluetooth Pairing and Using the 3.5 mm AUX Port sections for instructions.

- 1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode. The LED indicator will quickly flash BLUE.
- Set your mobile device to search for Bluetooth devices. When it appears, select ARBT52 from the list of found devices.
- 3. After a successful pairing, a tone will be heard, and the LED indicator will turn solid BLUE. You will be able to play music on the speaker.

In Bluetooth mode, playback and volume can be adjusted by the controls on the Front of the speaker, or by the controls on your paired device.

Press the utility button to pause and resume playback.

Press the + and — buttons to adjust volume.

- Press + hold the + and buttons to skip tracks.

When the speaker is paired to a phone via Bluetooth, the below phone functions can be used through the speaker controls.

- Press the O button to answer an incoming phone call. Press again to end the
- \bullet Press + hold the \bigcirc button to reject an incoming call.