

ART+SOUND™

Selfie Mic ARSSTKM05

CAUTION

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.**
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Do not allow the connector to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

Setting Up

Pull the top of the spring-loaded device holder up, and insert your device. The holder should grip the device securely.

Plug the selfie stick's attached 3.5 mm connector into the headphone jack or 3.5 mm audio port on your device. Some devices may require an adapter or dongle to work with the selfie stick. Consult your device's instruction manual for information.

Using the Selfie Stick & Mic

Install your device. On your device, open the karaoke, video or photo app you would like to use. The selfie stick & mic is compatible with most video recording photography apps.

- In photography mode, press the button on the side of the microphone to take a picture.
- In video mode, press the button on the side of the microphone to start or stop recording. The microphone will record your audio.

Using the Headphone Jack

You can listen to your device's audio through the headphone jack on the side of the microphone.

To use this feature, plug the 3.5 mm connector of your headphones (*not included*) into the 3.5 mm audio port on the side of the microphone.

Printed in China
Designed in USA
v1. 10-2021