### Using the Lights

- The LED lights will automatically power ON when the Bluetooth speaker is powered ON, and will cycle through different colors.

   When playing music, the LED lights will react to the beat of your music. For best results, turn the volume up.

   The LED lights will power OFF when the Bluetooth speaker is

### Cleaning and Maintenance

When you are finished using the humidifier, unplug and store the cable. Remove the humidifier from water, and allow the sponge

### Replacing the Sponge Wick

Replace the sponge wick every 3 months, or when it changes color.

Remove the lid, pull out the old sponge wick, and insert a new one. Be careful not to lose the spring that fits under the sponge wick when replacing. Replace the humidifier top.





FCC ID: 2APU8CQL1795-B Tracking Number: SO120020

Distributed By: 1616 Holdings Inc. 701 Market Street Philadelphia, PA 19016 USA

Technical Specs: Bluetooth Version 5.0 Driver Diameter: 45 mm Impedance: 3 Ohms Battery Capacity: 350 mAh Rechargable LI-ION Battery 3.7 V Charge Time: 1-2 hrs

### Legal Information

### **READ CAREFULLY AND KEEP THIS MANUAL**

**Caution**: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reasures:

  Reorient or relocate the receiving antenna.

  Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (f) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers, Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



### Rating Label Definitions





Bluetooth

This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SKI, i.e., and any use of such mark by Southern Telecom is under licenom is under licenom is under licenom.



This symbol represents FCC Declaration of Conformity and compliance.

### Warranty Information

### 90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product as supplied and distributed new by an authorized retailer is warranted by 
Southern Telecom, Inc. to the original consumer purchaser against defects in materials 
and workmanship ("Warranty") as follows:

### To obtain warranty service:

- To obtain warranty service:

  Visit our customer support portal: www.customersupport123.com

  Select the brand and model of your device

  Select Service Request\* and fill out the form to begin your inquiry

  Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper
installation or operation, lack of reasonable care, unauthorized modification including
software modifications such as the installation of custom firmware. This warranty is
voided in the event any unauthorized person opens, alters or repairs this product. All
products being returned to the authorized service center for repair must be suitably
navigations.

Dackaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APIPLY DISTRIBUTIOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY FOR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTIOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT UILL DISTRIBUTOR SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPOLICT SOLD BY DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPOLICT SOLD BY DISTRIBUTOR. SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPOLICT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

ome countries, states or provinces do not allow the exclusion or limitation of incidental consequential damages or allow limitations on warranties, so limitation or exclusions ay not apply to you. This warranty gives you specific legal rights, and you may have her rights that vary from state to state or province to province. Contact your thorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Getting Started

Wireless LED Speaker

asora

MANTRA

& Humidifier



# TXASOBTHUM-FB

User Guide

### Before You Begin

# Questions & Support

you have any questions or problems concerning this product, please sit our website at customerservice123.com

### Warnings and Information

### READ CAREFULLY AND KEEP THIS MANUAL

- · NOT INTENDED FOR MEDICAL USE. Do NOT use as a substitute for
- $\boldsymbol{\mathsf{medical}}$  attention. Do not expose the unit to extreme temperatures (heat or cold), open . This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manu use the device for anything other than its intended purpose.
- · Do not open this product or attempt to repair the unit yourself should
- it not be working. Doing so risks fire, shock or injury.
   If smoke or burning smell is detected, immediately unplug the unit.
- · Always unplug the power cable before maintenance Keep power cable clear of pathways, do not forcefully pull or remove
- Always keep the water container on a stable, flat surface, DO NOT place
- on a carpet, bed cushion or other non-flat, non-stable surface.

   Keep away from electronic equipment.
- · Do not submerge the humidifier top in water.
- Do not operate unattended, especially around children or any person(s) with reduced physical, sensory, or mental capabilities.
- se the supplied power cable. If using a USB adapter, it MUST be a
- 5 V USB adapter (not included).

  When not in use, the humidifier should be stored in a dry, cool location, away from sources of water or heat.

  It is recommended that the humidifier be covered to protect it from
- Do not add essential oil into the humidifying water. The oil will
- Do not allow the USB port or the connectors of the supplied USB cable
- to be exposed to dust, or water, or come into contact with any ve materials such as liquids, metallic powders, etc.
- · Low power may cause poor Bluetooth connection or sound
- Do not overcharge battery.
   The speaker contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

# Location of Controls

### In the Box:


- TXASOBTHUM-FB **Speaker & Humidifier** (x1)
- Micro-USB Charging/Power Cable (x1)

# Mist [Speaker LED Power] Indicator Switch Charging On Off )⊕ 🚍 [Humidifier Micro-USB 0.2.3 Charging/ Power] Power Port Sponge-Wick Humidifier

- Sponge Wick (x2)
   User Manual (x1)

Base


- 1. Pull the humidifier top up to remove.
- Pour water into the humidifier base's water tank. Use only clean tap water or mineral water. Do not use essential oils, as they can block humidification or damage the humidifier.
  3. For best results, wet the sponge wick completely for 2
- minutes before attempting to use. Be careful not to lose the spring that fits under the sponge wick.
- 4. Replace the humidifier top.



### Connecting to Power/Charging the Speaker

A Warning: Do not allow the charging/power cable, port or any power adapter (not included) to come into contact with water.

Plug the small connector of the included micro-USB cable into the charging/power port on the top. Plug the large  $\,$ connector into a USB power source such as the USB port on computer, or into a compatible 5V/05.A USB adapter (not included) and plug into a wall socket.



The LED indicator will light up RED when the speaker humidifier is connected to power.

- Using the Humidifier
  Set up the humidifier & connect to power. The humidifier cannot run on battery power, and MUST be connected to power in order to use the hamilifier functions.
- Press the [Humidifier Power] button to turn the humidifier ON
- Press the [Humidifier Power] button a 2nd time to switch to
- Press the [Humidifier Power] button a 3rd time to power the

**Note**: The humidifier will automatically power OFF after 4 hours in Continuous Mode, or 6 hours in Intermittent Mode. Turn on again

The speaker function ONLY can either be powered by the USB cable, or wirelessly & portably by the built-in battery. To run on battery power, charge the speaker humidifier fully before using.

To play music on the speaker, you must be paired to a Bluetooth-enabled device. If you are pairing for the first time, see the instructions in the **Bluetooth Pairing** section below.

Once you are paired via Bluetooth, all volume and playback adjustment will be controlled by your paired device.

# Powering the Speaker ON/OFF

### re the [Speaker Power] switch to power the speaker ON/OFF.

## Bluetooth Pairing 1. Power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode 2. Go to your device's Bluetooth Settings, and search for new Bluetooth devices. When it appears, select **TXASOBTHUM-FB**

m the found devices 3. After a successful pairing, a tone will be heard, and you will be

