

# Brookstone®

---

## **HDSOUNDBAR**

37" LED Home Theater Soundbar



# TABLE OF CONTENTS

Compliance Information.....	1
Before You Begin...	
Additional Warnings.....	3
In the Box.....	3
Location of Controls.....	4
Getting Started	
Wall Mounting the Speaker.....	5
Connecting to Power.....	5
Powering ON/OFF.....	5
Playing Music.....	6
Adjusting Volume.....	6
Using the LED Lights.....	6
Bluetooth Pairing.....	6
Using the 3.5 mm AUX Input.....	7
Using the Remote Control.....	7
Warranty Information.....	8

## FCC Information

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Radiation Exposure Information

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

## Rating Label Definitions

— — — Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., used under license.



Before You Begin...

## **READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE**


To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- **Do not disassemble, modify, or repair the device.**
- Do not expose the device to extreme temperatures (heat or cold), open flames, wet, or humid conditions.
- ***Do not submerge in water.***
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

### In the Box


- BSSK9037 - Wireless Speaker (x1)
- Power Adapter (x1)
- Remote Control (x1)
- Wall Mount Accessories (x1)
- Instruction Manual (x1)

## Location of Controls



## Wall Mounting the Soundbar

1. Remove the soundbar and its contents from packaging.
2. Using a pencil, mark two spots on a wall measuring 31.5 inches apart.
3. If installing to a wooden surface, hammer a nail, or drive or drill a mounting screw (*mounting materials not included*) into the wall at each marked location. If installing to drywall or a brick surface, you may need to install plastic anchors to properly secure the mounting screws.
4. Place and hang the soundbar from its mounting holes on the back onto the installed mounting nails or screws.




## Connecting to Power

Plug the pin of the supplied power adapter into the DC 9V power port on the side of the soundbar. Plug into an electrical outlet.

## Powering ON/OFF

- Turn the **[Volume]** dial *to the right* until it clicks to power ON. A tone will be heard, and the soundbar will enter Bluetooth pairing mode. It will automatically re-pair to any nearby, previously-paired device with Bluetooth enabled.
- Turn the **[Volume]** dial *to the left* until it clicks to power OFF.



## Playing Music

To play music on the soundbar, you must be paired to a Bluetooth-enabled device, or connected with an aux cable. See the **Bluetooth Pairing** and **Using the 3.5 mm AUX Input** sections of this manual for further instruction.

## Adjusting Volume

Adjust volume by turning the **[Volume]** dial on the soundbar, or use the controls on your connected device.

## Using the LED Lights

- Press the **[LED]** button on the soundbar or the **[LED]** button on the remote control to flip through LED light modes.

## Bluetooth Pairing

1. Power the soundbar ON. A tone will be heard and soundbar will enter Bluetooth pairing mode.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **BSSK9037** from the list of found devices.
3. After a successful pairing, a tone will be heard and you will be able to play music on the soundbar.

In Bluetooth mode, playback will be controlled by your paired device. Volume can be adjusted with the dial on the soundbar or with the controls on your paired device.



## Using the 3.5 mm AUX Input


Insert one connector of a 3.5 mm auxiliary cable (*not included*) into the 3.5 mm aux input port on the soundbar.

Insert the other connector into the headphone jack or 3.5 mm aux output port on your media-playing device. The soundbar will automatically switch to AUX mode.

In AUX mode, all playback will be controlled by your connected device.

## Using the Remote Control

- **[⏻]** Button: Enter/leave standby mode
- **[LED]** Button: Change LED light mode
- **[⏸]** Button: Pause/resume playback
- **[🔇]** Button: Mute/unmute volume
- **[▶⏩]** Button: Skip to next track
- **[⏪◀]** Button: Skip to previous track
- **[VOL+]** Button: Increase volume
- **[VOL-]** Button: Decrease volume



## Warranty Information

90-day Limited Warranty

Territory: United States/Canada

### **LIMITED WARRANTY TO ORIGINAL CONSUMER**

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship (“Warranty”) as follows:

To obtain warranty service:

- Visit our website at [www.southerntelecom.com](http://www.southerntelecom.com)
- Click on **Product Support**
- Select the **Brand** of your device
- Select **Service Request** and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

### Warranty (cont'd)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., used under license.

# Brookstone®

Brookstone© trademark, name and logos are trademarks of BKST Brand Holdings LLC and used under license.

Manufactured and Marked by Southern Telecom, Inc. under license.

Southern Telecom  
Brooklyn, NY 11220

Model No.: BSSK9037

1-888-550-9121 (Toll Free)  
Monday - Friday: 8AM - 10PM (EST)

Designed in US  
Printed in China  
v1. 09-2020