

Limited Warranty

90-day Limited Warranty
Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our website at www.southern telecom.com
- Click on **Product Support**
- Select the **Brand** of your device
- Select **Service Request** and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



Printed in China
v1. 06/2020



Wireless Charging Pad



User Guide
CW78

Before You Begin...

Charging Pad Safety Information

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- THIS DEVICE IS NOT A TOY.
- Do NOT allow children or pets to use or play with this device.
- Do not allow the device to be exposed to water or touch the device with wet hands.
- Do not drop or cause an impact to the device.
- Do not use or store the device in temperatures lower than 5°C or higher than 35°C.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- Do not disassemble, modify, or repair the device.
- Magnetic strip cards, including credit cards, phone cards, identification cards and boarding passes may be damaged by the magnetic field if placed on or near this device.
- Do not place this device on or near a microwave or similar kitchen appliance.
- This device should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Compatibility

CW78 is compatible with the following devices:

iPhone 8, iPhone 8 Plus, iPhone X, Asus Padfone X, Blackberry Z30 (Verizon), Blackberry Classic, Cat Catphone S50, DeWalt MIL810G, Google Nexus 4, Google Nexus 5, Google Nexus 6, Google Nexus 7, HP Elite X3, HTC 8X (Verizon), HTC Droid DNA (Verizon), HTC Thunderbold (Verizon), LG Optimus G Pro, LG G4, LG G3, LG G6, LG V30, Kyocera Hydro Elite, Kyocera Urbano L01, Kyocera Urbano L03, Kyocera Torque, Kyocera Torque G02, Lumia 950XL, Lumia 950, Lumia 950 Dual Sim, Motorola Droid Max, Motorola Droid Mini, Motorola Droid Turbo, Moto 360, MTT Master, MTT Master 4G, Nokia Lumia 920, Nokia Lumia 928, Nokia Lumia 735, Nokia Lumia 830, Nokia Lumia 930, Nokia Lumia 1520, Samsung Galaxy Note 8, Samsung Galaxy S8+, Samsung Galaxy S8, Samsung Note 5, Samsung 7 Edge, Samsung Note 7, Samsung S7, Samsung S6 Edge+, Samsung S6, Samsung S6 Edge, Saygus V Squared, Sony BSP10, Sony Xperia Z4V, Sony Xperia Z3V (Verizon), Yotaphone 2, Techdy Basic Bear, Vertu Signature Touch.

Using the Charging Pad

Question & Customer Support

For further assistance, please visit our website at SouthernTelecom.com. Click on **Product Support**.


In the Box

- CW78 - Wireless Charging Pad (x1)
- Micro-USB Power Cable (x1)
- User Manual (x1)

Setup

Plug the small connector of the supplied micro-USB power cable into the micro-USB port on the charging pad. Plug the large connector into the USB port on a computer, a USB power pack, or a **5V USB adapter** (not included) and plug into a wall socket.

The LED indicator on the bottom of the charging pad will **flash BLUE** to indicate that the charging pad has power.



Using the Charging Pad

After plugging in the charging pad, place your device in the center of the pad. The LED indicator will **turn solid BLUE** to indicate that it is charging.

If your device does not begin to charge, try repositioning it on the charging pad. **You may need to remove your smartphone case if you are using one.** After your device is fully charged, disconnect and unplug the charging pad.

Legal Information

READ CAREFULLY AND KEEP THIS MANUAL

FCC Information

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the requirements for Part 18 of the FCC Rules. Although this product complies with FCC, it may interfere with other devices. If this product is found to interfere with another device, separate the other device and this product.

RF Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Rain/Moisture Warning

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- Do not submerge in water.
- Do not open this product or attempt to repair the unit yourself should it not be working.

Rating Label Definitions

— — — Direct current



The FCC Declaration of Conformity is a certification mark which certifies that the electromagnetic interference from this device is under limits approved by the Federal Communications Commission.