

(Back Cover)

(Front Cover)

Compliance Information

·600.822.88

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, in not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guerantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

**Reorient or relocate the receiving antenna.

**Increase the separation between the equipment and receiver.

**Connect the equipment tind on outlet on a circuit different from that to which the receiver is connected.

**Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-on Battery Inside
This product is fitted with a Li-on battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to bigh temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.





Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, linc. and any use of such marks by Southern Felecom is under loense.



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original engagement retailer adjust distributed in materials and vorticements by Chartanty') as follows:

lect the brand and model of your device lect "Service Request" and fill out the form to begin your inquiry changes require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with

CWPRDSPK-FB



Tracking Code:SO030021

6. [Power] Switch

colorways

Portable Wireless Speaker



Instruction Manual CWPRDSPK-FB

Before You Begin...

Customer Support

For any questions or problems with your product, please visit our website at customersupport123.com.

↑ Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies, • THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with

- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water. Do not allow the speaker to get wet. Surface clean the speaker with a damp cloth ONLY
- Low power may cause poor Bluetooth connection or sound distortion.
 Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- The speaker contains a built-in battery, and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- CWPRDSPK-FB Wireless Speaker (x1)
 Micro-USB Charging Cable (x1)
- User Manual (x1)

Location of Controls Control Panel Under Silicone Cover Charging On Off 2 4 5 6 1. Carabiner 2. Silicone Cover 3. Bluetooth LED Indicator 4. Micro-USB Charging Port Back of 5. Charging LED Indicator

Getting Started

Charging the Speaker

Undo the silicone cover over the control panel on the back of the speaker. Plug the small connector of the included micro-USB charging cable into the micro-USB charging port on speaker. Plug the large connector into a USB power source such as the USB port on a computer, or plug into a 5V USB adapter (not included) and plug into a wall socket.

The charging LED indicator will turn RED while charging and turn off when fully charged. When fully charged, disconnect the charging cable, and place the silicone cover back over the control panel.

When low on power, a tone will be heard, indicating that the speaker should be

Powering ON/OFF

- Move the [Power] switch to power the speaker ON or OFF.
- When powered on, the speaker will enter Bluetooth pairing mode, and may automatically re-pair to a nearby previously-paired device.

- Bluetooth Pairing
 1. Power the speaker ON. A tone will be heard and the Bluetooth LED indicator will quickly flash BLUE.
- 2. Set your mobile device to search for Bluetooth devices. When it appears, select CWPRDSPK-FB from the list of found devices.
- 3. Once successfully paired, a tone will be heard and the Bluetooth LED indicator will slowly flash BLUE.

Once paired, all playback and volume adjustment will be controlled by your paired