



LOMI

4-IN-1 GEL SOCKS &
FOOT CARE KIT



User Guide
LOMB020

Before You Begin...

READ FULL MANUAL BEFORE USING & SAVE FOR FUTURE REFERENCE

NOT Intended for Medical Use

This product is designed as a non-professional device for skin care. **It is not intended to be a substitute for medical attention.** If your ailments persist or worsen after use, contact your doctor immediately.

Avoid using if you have any of the following skin conditions: severe rosacea, eczema, psoriasis, allergic reaction, skin lesions, dermatitis, sensitive skin, severe sunburn, swelling, irritation, or open wounds.

Please consult your doctor prior to using this product, if you have any concerns regarding your health.

Caution

- **THIS IS NOT A TOY, please keep away from children.**
- **Do not submerge in water.**
- Keep away from open flames, water, moisture, and extreme heat or cold.
- Supervision is recommended when this appliance is used by individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- Never operate this appliance if it is not working properly or if it has been dropped or damaged.
- Keep the appliance away from heated surfaces.
- Do not open this product or attempt to repair the unit yourself. There are no user-serviceable parts.

In the Box

- Gel Socks (x2)
- Electric Foot File (x1)
- Foot File Attachments (x2)
- Toe Separators (x2)
- Foot Scraper (x1)
- User Guide (x1)

Location of Controls



1. Plastic cover
2. Coarse grinding roller
3. Fine grinding roller
4. Power button
5. Battery compartment
6. Twisting lock

Installing Batteries

1. Twist the twisting lock at the base of the electronic foot file to unlock the battery compartment.
2. Pull off the battery compartment. Install 2 AA-sized batteries, following the polarity (+/-) diagram in the compartment.
3. Replace the battery compartment, and twist the twisting lock to lock.

Powering ON/OFF

- Press the Power button on the electric foot file handle to power ON/OFF.

Using the Electric Foot File

Install batteries, remove the plastic cover from the top of the electric foot file, and power ON.

Holding the handle, gently press the roller to the dead skin you want to remove. Slowly file away the skin.

Use the coarse grinding roller for thicker skin, and the fine grinding roller for less abrasive filing. Simply pull off to remove attachment, and push on to install.



Using the Foot Scraper

Use the foot scraper to remove calluses and the most coarse and rough dead skin.

Apply to the desired area. File slowly and gently until desired results.



Using the Toe Separators

The toe separators are great for holding the toes in place while you paint your toe nails.

Place toe separators in between toes before painting, and remove when finished.



Using the Gel Socks

For best results, wear the socks for 30-60 minutes after bathing your feet. If you have sensitive skin, do not use for more than 30 minutes.



Washing the Socks

Hand wash only in cool or warm (not hot) water. Do not bleach or use detergent. Do not iron. Do not dry clean. Lie flat to air dry, do not wring dry.

Warranty Information

90-Day Limited Warranty

Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com
- Select the brand and model of your device
- Select "Service Request" and fill out the form to begin your inquiry
- Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



LOMI

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China
Designed in the U.S.
v1. 09/2021