

LOMIMEN

PRECISION BEARD TRIMMER



User Guide
LOMMN119

Before You Begin...

READ FULL MANUAL CAREFULLY BEFORE USE AND KEEP FOR FUTURE REFERENCE

Important Safety Warning

Please consult your doctor prior to using this product if you have any concerns regarding your health.

Water Safety Warning - Shock Hazard

This device is NOT waterproof or water-resistant. Do NOT submerge in water.

- Remove comb before washing comb with water.
- Do NOT submerge trimmer in water, or get wet. Clean blades with included brush only.



General Warnings

- THIS IS NOT A TOY, please keep away from children.
- Follow all instructions. Use the appliance only for its intended uses as described in this manual.
- Keep away from extreme temperatures (heat or cold) and open flames. Store in a cool, dry location only.
- Supervision is recommended when this appliance is used by or on individuals with certain disabilities.
- Never operate an appliance if it is not working properly or is damaged.
- For hygienic reasons, the shaver should not be shared with others.
- Do not use on skin that is irritated, inflamed, infected or blistered.
- Keep the appliance away from heated surfaces.
- Do not operate after taking pain killers, sedatives or alcohol.
- Do NOT allow the blades or trimmer heads to come in contact with sharp or hard objects. It has a thin and easily damaged structure, and may harm your skin once damaged.
- Do not open this product or attempt to repair the unit yourself. If damaged, contact us at customersupport123.com.


In the Box

- Electric Trimmer (x1)
- Adjustable Trimmer Comb (x1)
- Cleaning Brush (x1)
- Blade Lubrication Oil (x1)
- Instruction Manual (x1)

Getting Started

Location of Controls

1. Blades
2. Removable Trimmer Comb
3. Head Adjustment Button
4. Power Switch
5. Battery Compartment



Installing Batteries

1. Press down on the battery cover on the back of the trimmer, and pull off.
2. Insert 2 AAA-sized battery (not included) into the battery compartment, following the polarity (+/-) diagram in the compartment.
3. Replace the battery cover, and push closed.



Powering ON/OFF



After installing batteries, move the Power switch on the trimmer to power ON/OFF.

Note: If the trimmer motor slows down in operation or becomes less efficient, you may need to replace the battery.

Installing & Adjusting the Trimmer Comb

To install or adjust the trimmer comb, hold down the head adjustment button, and slide the trimmer comb onto the top of the trimmer and into the desired setting 1-4. See chart at right for trimmer setting lengths.

Setting	Hair Length
1	5 mm
2	8 mm
3	11 mm
4	14 mm



Cleaning the Trimmer

Remove the comb from the trimmer. The comb may be rinsed under water, but do NOT rinse the trimmer under water.

The kit includes a small brush for cleaning the trimmer blades. After use, use the brush to clean off the trimmer blades.

Use the included oil to lubricate the blades only.

The body of the trimmer may be wiped with a damp cloth only. Do NOT immerse in water or any type of liquid, or allow the battery to get wet.



Storing the Trimmer

When not using for a long period of time, remove the battery and store the trimmer in a cool, dry location, away from sources of water, heat or dust. It is best stored in an airtight box or bag (*not included*).

LOMIMEN

Warranty Information

90-Day Limited Warranty

Territory: United States

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: **www.customersupport123.com** and select "**Support**".
- Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China
Designed in the U.S.
v1. 04/2022