







Mahli User Guide (Cover)

(Front)

 <p>MÄHLI Aroma Diffuser</p> <p>User Guide MDB1000</p>	<p>In the Box</p> <ul style="list-style-type: none"> • MDB1000 - Aroma Diffuser (x1) • Lavender Essential Oil (x1) • USB Power Cable (x1) • Instruction Manual (x1) <p>Location of Controls</p> 	<p>Setup and Use</p> <p>Powering the Diffuser To power the diffuser, insert the pin of the supplied USB power cable into the DC 4.5V power jack on the diffuser, and attach the other connector to the USB port on a computer or 5V USB adapter (not included) and plug into a wall socket. NOTE: If using your own USB adapter to power the diffuser, it MUST be a 4.5V - 5V adapter.</p> <p>If USB power is unavailable, you can insert 3x AAA-sized alkaline batteries (not included) into the battery compartment. When using batteries, make sure that the polarities are properly aligned as indicated on the inside of the battery compartment.</p> <p>When using batteries, do NOT mix alkaline, carbon-zinc, or any kind of rechargeable batteries. Do not mix different brands of batteries.</p> <p>Using the Diffuser 1. Before connecting to power, add 1-2 drops of essential oil to the oil cup. 2. Connect to power. 3. Press the [AROMA] button. The LED indicator will turn on while the aroma function is active.</p> <p>Using the Light • Press the [LAMP] Button to turn the diffuser's light ON/OFF.</p> <p>When finished, if using USB power, unplug the power cable from the diffuser. Drain any remaining oil from the oil cup, wipe the inside of the cup with a damp paper towel, and let dry.</p> <p>If you would like to more thoroughly clean the diffuser, use a small amount of neutral detergent, such as dish soap.</p> 	<p>Further Information</p> <ul style="list-style-type: none"> • The amount and intensity of aroma produced will vary. Factors that affect production of aroma can include water type, humidity, temperature, and/or air current. • Only 100% natural essential oil should be used with this product. Oil containing chemical fragrance, spice, or other impurities, may cause malfunctions. Only use 1 - 2 drops of essential oil. • ONLY use a 5V USB adapter to power this device with the supplied USB power cable. • When using batteries, if the diffuser's light is dimming or not turning on, you may need to replace the batteries. • ONLY use AAA-sized alkaline batteries for this device. Do NOT use any rechargeable batteries, carbon-zinc, ni-mh, ni-cad, etc. • If using batteries, it is recommended that they are removed if the diffuser is not in use for a long period of time. • When not in use, the diffuser should be stored in a dry, cool location, away from sources of water or heat. • It is recommended that the diffuser be covered to protect it from exposure to dust if it will not be in use for a long period of time.
--	---	---	--

<p>Precautions and Warnings</p> <ol style="list-style-type: none"> 1. Do not fill the oil cup over MAX level line. 2. Do not turn the aroma function on when the oil cup is empty. 3. Do not touch the inside base of the tank. 4. Clean regularly per the Maintenance instructions in this user manual to avoid malfunctions. 5. Always unplug the power adapter before maintenance. 6. Always pour any remaining oil out of the oil cup and wipe with a clean, dry cloth. 7. Essential oils can stain, in the event of a spill or leakage, please wipe away any water or oil with a soft cloth. 8. Do not let aroma blow directly onto furniture, clothing, art, or any valuable objects. 9. Keep away from direct sunlight, heat sources, air conditioners, or fans. 10. Always keep on a stable, flat surface. Do NOT place on a carpet, bed, cushion or other non-flat, non-stable surface. 11. Keep away from electronic equipment. 12. Do not tip the product as it may cause oil to enter the mechanism and cause malfunction. 13. Do not use for more than 2 hours at a time. 14. Never move the product while in-use. 15. Do not touch any part of the product with wet hands. 16. Keep out of reach of children and pets. Children should not be left unsupervised near this product. This unit is not to be used by children or any person(s) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given express supervision and instruction. 17. Keep the DC power jack clear of pathways, and do not forcefully pull or remove from the unit. 18. If smoke or burning smell is detected, immediately unplug the unit. 	<p>Legal Information</p> <p>READ CAREFULLY AND KEEP THIS MANUAL</p> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.</p> <p>Rating Label Definitions</p> <p> Direct current symbol</p> <p> This symbol represents FCC Declaration of Conformity and compliance.</p>	<p>Limited Warranty</p> <p>90-day Limited Warranty Territory: United States/Canada</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> • Visit our website at www.southern telecom.com • Click on Product Support • Select the Brand of your device • Select Service Request and fill out the form to begin your inquiry <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p><small>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY, NOTWITHSTANDING THE FOREGOING. CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</small></p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p>	 <p>MÄHLI</p> <p>Made in China/Designed in the U.S. v4, 12/2020</p>
--	---	--	--

(Back)