Legal Information

READ CAREFULLY AND KEEP THIS MANUAL

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
This device has been evaluated to meet general RF exposure requirements.
The device can be used in portable exposure conditions without restriction.

Rating Label Definitions



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-day Limited Warranty Territory: United States/Ca

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

- To obtain warranty service:

 Visit our website at www.southerntelecom.com

 Click on Product Support

 Select the Brand of your device

 Select the Brand of your did the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE SHALL APPLY DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTES AFTER THE EXPRESS WARRANTY FERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BRIDNED ON DISTRIBUTORS. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS SOLE DISCRETION - ARE THE EXCLUSIVE REMOBLES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTIAL, DIRECT, NOIRECT, TRECAL, DUNITIVE OR CONSOCIOUNTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAWINGS, DATA OR RECORDS) CAUSED BY THE USE MUSICS OR INSIDIATIVE TO VERY THE PROPOLITE EXCEPT AS STATED HEREN, NO OTHER WARRANTIES SHALL APPLY, NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEPT THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



MALLI

Cute Critters Cool Mist Humidifier



User Guide MDB1080

Before You Begin

Questions & Support

f you have any questions or problems concerning this our website at SouthernTelecom.com and click on Pro

- our website at SouthernTelecom.com and click on Product Support.

 Warnings and Information

 NOT INTENDED FOR MEDICAL USE

 This device is not intended to be a substitute for medical attention.

 Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions or wet conditions.

 If smoke or burning smell is detected, immediately unplug the unit.

 Do not touch the atomizing sheet to avoid scalding.

 Always unplug the power adapter before maintenance.

 Keep power cable clear of pathways, do not forcefully pull or remove from the unit.

 Always keep on a stable, flat surface. DO NOT place on a carpet, bed cushion or other non-flat, non-stable surface.

 Keep away from electronic equipment.

 Never move the product while powered on.

 Do not submerge in water.


 Keep out of reach of children and pets. Children should not be left unsupervised near this product. This unit is not to be used by children or any person(s) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge unless they have been given express supervision and instruction.

- experience and knowledge unless us of the state of the st
- away from sources of water or heat.

 It is recommended that the humidifier be covered to protect it from
- Do not add essential oil into the product. The oil will damage the


- MDB1080 Humidifier (x1)
 USB Power Cable (x1)
- User Manual (x1)


Location of Controls



- 1. Twist the cover to the left and pull up to remove.
- 2. Dampen the sponge wick before use. When disassem-bling the sponge wick, be careful not to drop the spring. The spring must be installed below the sponge wick in order to produce
- 3. Fill the tank up to the marked "Max level" line with room temperature water.
- CAUTION: Only use clean tap water or mineral water. DO NOT use pure or distilled water, otherwise water will accumulate on the atomizing sheet, and may result in sputtering. DO NOT add essential oils/ perfume to damaged.
- 4. Secure the cover back on the tank, and place the humidifier on a flat, stable surface.
- 5. Insert the small end of the supplied USB power cable into the power port on the side of the humidifier and plug into a USB port on a computer or 5V/1A USB adapter (not included) and plug into a wall socket.







Using the Product

- Press the [Function] button to power the product ON. The humidifier function will start, and the light will start cycling through colors. A timer will begin, and the product will automatically power OFF after 4 hours.
- At any time, press the [Function] button again to power the product OFF.
- When the product is ON, press and hold the [Function] button (-3 seconds) to pause on the current light color.
- · Press and hold the [Function] button again to power the light OFF, leaving the humidifier ON.

 Press and hold the [Function] button again to power
- the color cycling light back ON.

Cleaning and Maintenance

When you are finished using the humidifier, unplug the cable,

Gently wipe the inside of the tank with a clean cloth or rag. Do NOT use any soaps or detergents to clean the water

For best results, we recommend replacing sponge wicks