Connecting to Two Bluetooth Devices

To connect two Bluetooth devices to the same headset:

- 1. Connect the first Bluetooth device to the headset following the instructions in the Bluetooth Pairing section of this manual.
- 2. On the second Bluetooth device, open Bluetooth Settings, and search for new devices.
- Select PBA105 from the list of found devices.
- 3. Return to the first Bluetooth device's Bluetooth Settings. Select PBA105 again.
- 4. The headset should now be connected to both Bluetooth devices.




When the headset is paired to two devices:

- The headset can intercept and answer a phone call that comes through on either device.
- Audio can only be listened to on one device at a time. If you wish to play audio from the other device, pause or turn off audio on the first device, and begin audio playback on the second device.

Phone Calls

To use the phone functions on the headset, you must be connected to a Bluetooth-enabled device.

- Press the ſ ₺ 1 button to answer an incoming phone call. Playback will automatically pause
- While on a phone call, press the [] button to mute/unmute the microphone.
- Press + hold the [(b)] button for 3 seconds to hang up a phone call.
- Press + hold the [🕁] button for 3 seconds to reject an incoming call.



Compliance Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- . Regrient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label





RC This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom. Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com
- Select the brand and model of your device Select "Service Request" and fill out the form to begin your inquiry.
- Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL DIRECT INDIRECT SPECIAL PUNITIVE OR CONSCOUENTIAL DAMAGES ISUCH AS BUT NOT LIMITED TO DAMAGES FOR LOSS OF PROFITS BUSINESS SAVINGS DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY, NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China v1. 02-2021

packard bell

PBA105 **Wirelesss Headset** Instruction Manual



Before You Begin

READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this.


- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this
 device.
- Do not disassemble, modify, or repair the device.
- Do not expose the device to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- . Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- . If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- PBA105 Headset (x1)
- Micro-USB Charging Cable (x1)
- Instruction Manual (x1)

Customer Support

For any questions or problems with your product, please visit our website at **customerservice123.com**.




Getting Started

Charging the Headset

Plug the small connector of the included charging cable into the charging port on the headset earcub. Plug the large connector into a USB power source such as the USB port on a computer, or into a **5V/1A USB adapter** (not included) and plug into a wall socket.

The headset LED indicator will **slowly flash RED** while charging and **turn solid RED** when fully charged.

On low battery, a red light will flash and the headset will automatically power OFF. Please recharge when this happens.



Powering ON/OFF

- Press + hold the [⊕] button for 5 seconds to power the headset ON or OFF.
- When powered on, a voice will be heard and the headset will enter Bluetooth pairing mode. They may automatically re-pair to any nearby, previously-paired device with **Bluetooth enabled**.
- Note: The headset will automatically power OFF if it is not paired to a Blutooth device after 30 minutes.

Playing Music

To listen to music on the headset, you must be paired to a Bluetooth-enabled device. Consult the **Bluetooth Pairing** below for further instruction.

Adjusting Volume & Playback

- While playing music, press the [] button to pause and resume playback.
- Press the [+] and [] buttons to adjust volume.
- Press + hold the [+] and [] buttons to skip tracks.

Bluetooth Pairing

- 1. Power the headset ON. The LED indicator will flash BLUE quickly.
- Go into your device's Bluetooth Settings, and search for new devices. When it appears, select PBA105 from the list of found devices.
- 3. After a successful pairing, the LED indicator will *turn solid BLUE*.

In Bluetooth mode, playback and volume can be adjusted with the on-ear controls listed in the **Adjusting Volume & Playback** section above, or with your paired device.

 Press + hold the [] button to disconnect a Bluetooth pairing and re-enter Bluetooth pairing mode. The LED indicator will flash BLUE quickly when the headset is ready to pair again.

Muting/Unmuting the Microphone

- Press the [] button to mute or unmute the micrphone while on a call, or while using the mic.
- Note: If you are listening to music on the headset, pressing the [ψ] button will pause and resume audio playback.

