

User Manual

PBBTH11

(Fold Inward) — — — — — 


(Back Cover)

(Front Cover)

Playing Music






To listen to music on your headphones, make sure they are paired to a Bluetooth-enabled device or connected via 3.5 mm auxiliary input.

Bluetooth Pairing

1. Press and hold the [] button for **7 seconds** to set the headphones into pairing mode. A tone will be heard and the LED indicator will **flash GREEN and BLUE**.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **PBBTH11** from the list of found devices.
3. Once successfully paired, a tone will be heard and the LED indicator will turn **solid BLUE**.



Controlling Playback & Volume

- Press the [] button to pause/resume media playback.
- Press the [] and [] buttons to skip tracks.
- Press and hold the [] and [] buttons to adjust volume. A tone will be heard if trying to increase the volume past the maximum level.

Connecting with the 3.5 mm Input

1. Insert one connector of the supplied 3.5 mm auxiliary audio cable into the 3.5 mm auxiliary audio input jack.
2. Insert the other connector of the cable into the audio output or headphone jack of your media-playing device.
3. Adjust playback with the controls on your media-playing device.

packard bell

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Designed in US
Printed in China
v1. 05-2021

packard bell

PBBTH11
Wireless Headphones
Instruction Manual



Before You Begin...

Customer Support

For any questions or problems with your product, please visit our website at customersupport123.com.

⚠ Caution


To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- PBBTH11 - **Wireless Headphones** (x1)
- USB Charging Cable (x1)
- 3.5 mm Auxiliary Audio Cable (x1)
- User Manual (x1)

Location of Controls




Getting Started

Charging the Headphones



Attach the small connector of the supplied micro-USB cable to the USB charging port on the side of the left earcup. Attach the large connector to the USB port on a computer, a USB charging device, or a **5V USB adapter** (not included) and plug into a wall socket.





The LED indicator will **turn RED** while charging and turn off when fully charged. When low on power, a voice will be heard, indicating that the headphones should be charged.

Power ON/OFF

- Press and hold the [] button to power the headphones ON/OFF.
- When powered ON, the headphones will automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled.

Phone Calls

- Quick press the [] button to answer an incoming phone call. Quick press again to end the phone call.
- Press and hold the [] button for 2 sec. to send an incoming phone call straight to voicemail.

| LED Indicator | |
|---|--|
|  | Flashing GREEN & BLUE Headphones are ready to pair |
|  | Solid BLUE Headphones are paired |
|  | Solid RED Headphones are charging |
|  | Off Headphones are fully charged |