User Manual - PBH401

Front Page

Panel Size: 5"(h) x 3.5"(w)

- Go to our website portal to receive an SRO number.
 Provide proof of the date of purchase within the package (dated bill of
- Prepay all shipping costs to the authorized service center, and remember
- Prepay all snipping costs to the authorized service center, and the to insure your return.
 Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
 Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or result of shipping will require you to file a claim with the carrier.

of the authorized service center is: Customer Service Dept. 36

Should you have any questions or problems concerning this product, please visit our website at:

SouthernTelecom.com and click on Product Support.

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably

- Limitation of Warranty

 THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

 REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTIBILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE. APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Android, Google and the Google Play store logo are registered trademarks of Google Inc., used with permission.

Apple, iOS, and the App Store are registered trademarks of Apple Inc., registered in the U.S. and other countries.

Packard Bell® is a Registered Trademark of JMM Lee Properties, LLC and

All other trademarks and trade names are those of their respective owners.



WI-FI MULTICOLORED LIGHT BULB





PBH401 - Wi-Fi Multicolored Light Bulb (x1)
 User Manual (x1)

This product works together with the PackardHome mobile app for Android and iOS devices. Make sure that your device's operating system

Please also check that your Wi-Fi router is working properly and that the Wi-Fi network you are connected to is a 2.4GHz channel, with WPA/WPA2





PackardHome iOS 8 0+

- for the **PackardHome** app on the **Apple App Store** or the **Google**
- 2. Launch the PackardHome app and login to your account or select Sign
- Up if you do not already have an account.

 3. Follow the instructions to create an account. An activation email will be
- sent to your email account to complete the sign up process.

icon and select **User Guide** on the menu. The in-app user guide will explain how to use the app itself, whereas this user guide focuses on setting up the device and the **PackardHome** app.

- Move to the area that you plan on using the light bulb. Check that the Wi-Fi signal is strong enough to connect and maintain a connection on
- This bulb is designed to fit an **E26-size** light fixture; make sure the light
- · Turn OFF the power to the light fixture.
- Install the PackardHome app on your mobile device

Make sure your mobile device is connected to a **2.4G Wi-Fi network**. 2.4GHz is the default channel type for Wi-Fi networks, 5GHz networks will typically have "5G" appended to their network name

NOTE: It is important that you connect the light bulb in the exact area that you plan on sing it. The light bulb requires a stable Wi-Fi signal to properly operate.

Open and login to the **PackardHome** app.

- 2. Tap the devices tab, swipe to the Light tab, and tap the [+] icon at the top of the page.

 3. Follow the instructions on screen to input your Wi-Fi network credentials
- and scan the QR code on the senso
- 4. Screw the light bulb into the light fixture, if you have no done so, already,
- 5. Tap the **Pairing** button on the screen and wait for the light bulb to pair.

On a successful connection, the PackardHome app will return to its home n where the light bulb will be displayed

If the pairing attempt times out, the PackardHome app will display a e and return to its home screen. Unscrew and remove the light **bulb** and repeat the steps above.

- Do not place any magnets or magnetized materials near the sensor as it may trigger or disrupt the connection to your PackardHome network.
 Make sure your Wi-Fi network and its signal strength covers the area that the sensor is placed. Please note that a Wi-Fi signal may not penetrate through concrete walls or solid doors and that, if it does, the strength of the signal will most likely be SEVERELY reduced.
 After installing a light bulb, test it to make sure it is operating properly and that the Wi-Fi signal is strong enough.
- and that the Wi-Fi signal is strong enough.

 The alarm can be configured or muted inside the app.

For any questions, please visit our website at:

SouthernTelecom.com and click on Product Support.

READ CAREFULLY AND KEEP THIS MANUAL

RCC Information

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undersired operation.

PBH401 Wi-Fi Light Bulb

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- · Do not open this product or attempt to repair the unit yourself should it