



PBSK205 CYPHER Blacklight Gaming Speaker User Manual

Before You Begin...

READ CAREFULLY AND KEEP THIS MANUAL

Customer Support

For any questions or problems with your product, please visit our website at **customersupport123.com**.



To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- THIS DEVICE IS NOT A TOY, keep away from children and pets.
 - . Do not disassemble, modify, or repair the device,
 - Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.


Do not submerge in water.

- Low power may cause poor Bluetooth connection or sound distortion.
- . Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders. etc.
- The speaker contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- PBSK205 Wireless Speaker (x1)
- Neon Marker (x1)
- USB Type-C Charging Cable (x1)
- Cleaning Cloth (x1)
- User Manual (x1)

Location of Controls



- 1. Power Button: Power ON/OFF
- 2. Bluetooth LED Indicator
- 3. Button: Play/pause, answer/end call, reject incoming call, redial
- 4. Button: Decrease volume, skip to previous track
- 5. + Button: Increase volume, skip to next track
- 6. Microphone
- 7. Writing Board Light 🔆 Button
- 8. USB Type-C Charging Port
- Charging LED Indicator
- 10. Writing Board

Getting Started

Charging the Speaker

Plug the small connector of the included charging cable into the charging port on the back of the speaker. Plug the large connector into a USB power source, such as a **5V/1A USB adapter** (not included).

The charging LED indicator will **turn RED** while charging and turn OFF when fully charged. When the speaker is low on power, a tone will be heard indicating that it needs to be recharged.

Powering ON/OFF

- Press + hold the Power button to power ON and OFF.
- When powered ON, the speaker will automatically enter Bluetooth pairing mode, and may automatically re-pair to a previously-paired device nearby.



Bluetooth Pairing

- Power the speaker ON, and switch to Bluetooth input mode. The LED indicator will quickly flash BLUE.
- Set your mobile device to search for Bluetooth devices. When the list appears, select PBSK205 from the found devices.
- After a successful pairing, a tone will be heard and the LED indicator will slowly flash BLUE.

Adjusting Volume

Volume can be adjusted with the buttons on the top of the speaker or with the controls on your paired device.

- Press the + button to increase volume.
- Press the button to decrease volume.

Adjusting Playback

In Bluetooth, FM Radio, TF and USB modes, playback can be controlled by the buttons on the top of the speaker.

- Press the > button to pause playback. Press again to resume.
- Press + hold the + button to skip to the next track.
- Press + hold the button to skip to the **previous** track.

Phone Calls

When the speaker is paired to a device, the following phone functions are available.

- Press the button to answer an incoming phone call. Press again to end the call.
- Press + hold the button to reject an incoming phone call.
 2x Press the button to redial the last outgoing number.

Using the Light-Up Writing Board

- Use the included neon marker to write on the writing board.
- Use the built-in eraser on the other end of the marker or the cleaning cloth to erase writing.

To Use the Backlight:

- When the speaker is on, press the * button to turn the writing board's backlight ON in sound reactive mode. The light will dance to the sound of your audio. For best results, turn up the volume.
- Press the -xx- button a 2nd time to enter solid light mode.
- Press a 3rd time to turn the light OFF.

Note: The light can only be turned on when the speaker is on. If the speaker is powered OFF, the light will turn OFF automatically.

Compliance Information

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the eauipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pur-

suant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label Definitions

=== Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-day Limited Warranty

Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com
- Select the brand and model of your device
- . Select "Service Request" and fill out the form to begin your inquiry
 - · Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THANTHOSE EXPRESSY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES, AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, NO OTHER EXPRESS WARRANTY OF ALL WARRANTY GENE ANY PERSON, IRIM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OT THE CONSUMER, IN NO EVENT WILL DISTRIBUTOR OR ITS WANDLAGTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, NOTIFICATION, AND THE EXCLUSIVE REMEDIES OF THE ORIGINAL GRADULAR PURPOSE OF THE STATE OF THE VICENTIAL PURPOSE OF THE STATE HEREIN, OF THE STATE OF

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or diminisations or warranties, so limitation or exclusions may not apply to you. This warranty gives you specifie legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty apolies.





Designed in US Printed in China v1. 10-2021