



# TECHUP

**TCU360**

## **IntelliStand**

Auto-Tracking 360-Degree Phone Holder

Instruction Manual



# Before You Begin...

## **READ CAREFULLY AND SAVE THIS MANUAL**


### Caution

- **THIS IS NOT A TOY, please keep away from children & pets.**
- Do NOT expose to water, fire, high temperatures, or humidity.
- Do not touch with wet hands.
- Do not drop or cause an impact to the device.
- Do not use or store the device in temperatures lower than 5°C or higher than 35°C.
- Do not disassemble, open, or attempt to repair this product under any circumstances. There are no user-serviceable parts.
- **Always pay attention to your surroundings when using. Always use with caution.** Do not use to shoot photo or video in circumstances or an environment that could result in injury. Use at your own risk.

### In the Box

- TCU360 - IntelliStand Phone Holder (x1)
- Instruction Manual (x1)

# Location of Controls



# Getting Started

## Installing Batteries

1. Remove the battery compartment cover.
2. Install 3 new 1.5V AA-sized batteries following the polarity diagram (+/-) in the battery compartment. Do not mix old and new batteries or mix different brands or types of battery.
3. Replace the battery compartment cover.

## Installing Your Device

Pull the spring-loaded phone holder open, and place your device inside. Let the holder close around your device. It should hold it securely.

## Switching Holder Direction

Loosen the knob to release the phone holder. Switch between vertical and horizontal direction as desired. Turn the knob to lock again.

## Powering ON/OFF

- Press the **[Power]** button to power ON. The LED indicator will flash RED.
- Press + hold the **[Power]** button to power OFF. The LED indicator will turn OFF. After powering OFF, you will need to *press + hold* if to power ON again.

**Instructions continued on the next page.**

## Connecting Your Device

1. Power the IntelliStand phone holder ON. The LED indicator will flash RED, and it will search for Bluetooth devices.
2. Scan the barcode below to bring up the Live360 Phone App.

iOS



Android



Download the app, and open. Follow the instructions in the app to set up and use your IntelliStand phone holder.

3. After a successful pairing, the connection will appear on your device's screen and the LED indicator will flash BLUE.

**Note:** The phone holder will automatically power OFF if there is no Bluetooth connection after 40 seconds.

# Warranty Information

## 90-Day Limited Warranty

Territory: United States/Canada

### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

#### To obtain warranty service:

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com)
- Select the brand and model of your device
- Select "Service Request" and fill out the form to begin your inquiry
- Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

#### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

Printed in China/Designed in the U.S.

v2. 01/2022