ΤΓΛΧΧ

Cell Phone Detention TXPHNJAIL-FB

CAUTION

To ensure safe and proper use, read all safety information before using the device. • THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device

In the Box

- Light Grey Jail Roof (x1)
- Black Slotted Jail Floor (x1)
- Grey Left and Right Jail Cell Walls (x2) Grev Back Jail Cell Wall (x1)
- · Jail Cell Door with Hinges (x1)
- Padlock (x1)
- Keys (x2)

Setting Up

- 1. Locate the arrows on the each of the 3 jail walls that are not the door, which has a black piece attached to the bottom. Snap the connecting tabs of the 2 smaller (left and right) walls into the small slots on the sides of the bigger (back) wall so that all the walls' arrows are pointing in the same direction, and all of the arrows are on the outside of the structure.
- 2. Line the holes on the underside of the light grey-colored jail roof up with connecting tabs of the 3-wall structure, with the wall arrows pointing away from the roof. Press the roof onto the 3 walls until they snap together.
- 3. Line the connecting tabs on the other end of the 3 walls (the tabs that have the arrows on them) up with the thin outer slats on the black jail cell floor. Press the bottoms of the jail walls into the slats until they snap into place.
- 4. Place the jail cell door on the front of the jail, lining up the lock hole of the door with the lock hole of the left jail wall. Press the two clasps on the right side of the jail door onto the closest bar of the right jail wall, until they both snap on. This is the door's hinge.

Using the Phone Jail

Set up the jail. Place cell phones inside, into the holding slots on the floor of the iail.

Unlock the included padlock with one of the included keys, and slide the shackle of the padlock through the two holes on the outside of the jail cell to fasten the door closed. Push the lock closed to lock shut.

Open and close the padlock using the included keys.

Warranty Information

90-day Limited Warranty rritory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service: • Visit our website at www.southerntelecom.com Click on Product Support

Select the Brand of your device

· Select Service Request and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province Contact your authorized retailer to determine if another warranty applies.



Tracking Number: MA110019

Distributed By: 1616 Holdings, Inc 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China | Designed in the USA

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China Designed in USA v1.01-2020