Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

 $\textbf{Caution:} \ \, \textbf{Any changes or modifications not expressly approved could void the user's authority to operate the equipment.}$

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.


-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
This device has been evaluated to meet general RF exposure requirements, The device can be used in portable exposure conditions without restriction.



Warranty Information

90-day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

- To obtain warranty service:

 Visit our website at www.southerntelecom.com

 Click on *Product Support* Select the *Brand* of your device

 Select the *Brand* of your did to the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

ADIY PACKAGGEO.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT FAILL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL DIRECT, INDIRECT, SPECIAL, PUNTIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAMINOS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS STATED HEREIN NO OTHER WARRANTIES SHALL APPLY, NOTWITH STANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT OLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXCEPT TO ANYONG OTHER THAN THE ORKINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies,



Printed in China/Designed in the U.S. v1. 08/2020

Beauty Refrigerator Skincare & Makeup



Instruction Guide OLIF8000

Before You Begin...

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE. FOLLOW ALL INSTRUCTIONS. KEEP THIS MANUAL FOR FUTURE REFERENCE.

▲ Caution

ire safe and proper use, read and follow all instructions. Only use anufacturer-approved batteries, chargers, accessories, and supplies.

- THIS IS NOT A TOY, please keep away from children.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended Do not open this product. Do not attempt to modify or repair
- the unit. Doing so risks shock, burn and injury.

 Do not expose the unit to extreme temperatures (heat or cold), open flames, flammable items, or humid or wet conditions.

 DO NOT submerge or rinse under running water.

- Do not use the refrigerator to preserve sensitive medication.
 Always keep ventilation openings clear of obstruction. Do not allow any ports, vents, inputs or connectors of the device or power adapter to be exposed to dust or water, or come into contact with any conductive materials such as liquids, metallic
- powders, etc.
 Do not use in a poorly ventilated area. Allow at least 2 inches of distance from the back and sides of the device to allow proper. air circulation and heat dispersal.
- To ensure optimal performance, keep the cooler/warmer unit's fans clear of dirt and debris. Stuck fans will overheat the unit and can pose a potential fire hazard.
- Do not place any cloth or paper products on the unit.
 This unit ONLY works on 110-240V power supply.
- When packing the unit, do not place upside-down
 DO NOT use other electrical appliances inside the storage compartments of the appliance.
- When plugging in the unit, ensure that the power cord is inserted tightly into the socket. A loose socket can cause damage or fire.

 If the supplied power adapter is damaged in any way, DO NOT
- attempt to repair it. Damaged power cords must be replaced by the manufacturer.

Questions & Support


If you have any questions or problems concerning this product, please visit our website at SouthernTelecom.com

Getting Started

In the Box

- User Manual (x1)





Back of Refrigerator

OLIF8000 - Beauty Refrigerator (x1) AC Power Adapter (x1)

- DC Car Adapter (x1)
 Removable Storage Slot (x1)
- Removable Shelf (x1)

Front of Refrigerator

Using the Car Adapter

Connecting to Power

Connecting to Wall Power


the electrical plug into a wall outlet

Plug the 2-pin connector of the included car adapter into the DC power port on the back of the refrigerator. Plug the car adapter's 12V plug into the 12V DC automobile auxiliary power

Choose a location for the refrigerator near a wall power outlet or a 12V DC automobile auxiliary power outlet (cigarette lighter), away from sources of light, heat, moisture and dust. Make sure there are at least 2 inches of distance on every side

Plug the two-pin connector of the included power adapter into the AC power port on the back of the refrigerator. Plug

of the refrigerator so it can properly ventilate.



- Use only with a 12-Volt outlet. Do NOT connect directly to the 24-Volt outlet of a heavy duty vehicle.
- Do not leave the refrigerator plugged in for a long time while the engine is not running, as this can drain the car's battery.
- · Never leave the refrigerator running in a poorly ventilated

Using the Refrigerator

For best results, cool or warm your beauty products before placing them in the refrigerator. The refrigerator is not designed to cool down or heat up products, but to keep them

Move the [Mode] Switch on the back of refrigerator to select

- a temperature mode.
 Select the "COOL" position for cooling mode. The COOL Indicator light on the back of the refrigerator will light up GREEN.
- Select the "WARM" position for warming mode. The WARM Indicator light on the back of the refrigerator will light up RED.
- If you are switching between temperature modes, be sure turn the refrigerator OFF for 30 minutes in between the

Cleaning & Maintenance

Disconnect the refrigerator from power before performing any cleaning or maintenance on it.

The air intake vent on the back of the refrigerator should be

The surfaces of the refrigerator can be cleaned with a damp

cloth and mild cleaner.

Never submerge the refrigerator in water or liquid.

Never allow any ports, vents or connectors to come into

contact with liquid Do not touch with wet hands Allow the refrigerator to dry completely before connecting

to power again.

When the refrigerator will not be used for a long period of time, it should be stored away.

It is best stored in an airtight box or bag (not included), away from sources of light, heat, dust and moisture.