

PBT118

User Guide

(Front)



User Manual
PBT118



Sport-Fit LED Neckband Earbuds

Before You Begin...

Questions?
Need some help?
This manual will help you
enjoy your new product



or visit us at:
SouthernTelecom.com
Click on "Product Support"



CAUTION

- **THIS IS NOT A TOY, Please keep away from children**
- Keep away from water and extreme temperatures
- Low power may cause poor Bluetooth connection or sound distortion
- Do not overcharge the battery
- If using while exercising, please always be aware of your surroundings ESPECIALLY when outside or near vehicles

In the Box

- PBT118 - Wireless Earbuds (x1)
- Micro-USB Charging Cable (x1)
- Extra Silicone Eartips (L & S) (x1)
- User Manual (x1)

Earbuds Information


- Bluetooth Specification: ver. 4.1+EDR
- Operating Distance: 30 ft
- System Requirements: Bluetooth-capable device

Battery Information

- Built-In Battery: 3.7V mAh, Lithium-ion
- Input: DC 5V
- Charging Time: 2 - 3 hours

Location of Controls

1. [◀] Button: Skip to previous track
2. [▶] Button: Skip to next track
3. [⏸] Button: Pause/resume playback
4. (Inside Arm) Micro-USB Charging Port
5. [+] Button: Increase volume
6. (Outside Arm) [Power] Switch
7. [-] Button: Decrease volume
8. [📞] Button:
(Quick Press) Answer/end phone calls
(Long Press) Reject incoming phone call
(Double Press) Redial last incoming number



Using the Earbuds

Charging the Earbuds

Insert the small connector of the supplied USB cable into the micro-USB charging port on the inside arm of the earbuds. Insert the large connector into the USB port on a computer, USB charging device, or a **5V USB adapter** (not included) and plug into a wall socket.

The LED lights on the earbuds will **turn RED** while charging and turn off when fully charged. When the batteries on the earbuds are low, a tone will be heard and the LED lights will **flash RED**.

Powering ON/OFF

- Slide the [Power] switch to the ON position to power the earbuds ON. A tone will be heard, the LED lights will briefly **turn BLUE**, and then the earbuds will automatically enter Bluetooth pairing mode.
- Slide the [Power] switch to the OFF position, the LED lights will briefly **turn RED** and the earbuds will power OFF.

Adjusting Volume

- Press the [+] and [-] buttons to adjust volume.

Phone Calls

- Quick press the [📞] button to answer an incoming phone call. Press a second time to hang up.
- Long press the [📞] button to reject an incoming phone call.
- Double quick press the [📞] button to redial the last phone number called.



Be sure to charge the earbuds for 2 - 3 hours before using for the first time.

Playing Music

To enjoy music wirelessly on your earbuds, make sure they are paired to your Bluetooth-enabled device. Once paired, you can control the media playback and volume adjustment with the controls on your paired device or the controls listed below.

Bluetooth Pairing

1. Power the earbuds ON. A tone will be heard and the LED lights will **quickly flash RED and BLUE**.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **PBT118** from the list of found devices.
3. Once successfully paired, a tone will be heard and the LED lights will **slowly flash BLUE**.

If the earbuds do not automatically reconnect, make sure that Bluetooth is enabled and that the earbuds are within range of the Bluetooth device.

Pause/Resume Playback

- Press the [⏸] button to pause audio playback. The LED lights will **flash BLUE** while music is playing.
- Press the [▶] button again to resume audio playback.

Skipping Tracks

- Press the [◀] and [▶] buttons to skip tracks.



Legal Information

READ CAREFULLY AND SAVE FOR FUTURE REFERENCE

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Frequency Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.


Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR, IP Holdings, LLC, used under license.

PLR IP Holdings, LLC does not manufacture this product or provide any manufacturer's warranty or support.

www.polaroid.com ©2020 All rights reserved

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.



Legal Information (cont'd)

WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



The crossed-out garbage bin symbol means that you must not dispose of this product together with unsorted household waste.

Rain/Moisture Warning

- Do not expose the unit to extreme temperatures (heat or cold), open flames, etc.
• Do not allow this unit to get wet
• Do not open this product or attempt to repair the unit yourself should it not be working.

Rating Label Definitions

Direct current symbol.

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.

Warranty Information

90-day Limited Warranty

Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our website at www.southerntelecom.com
• Click on Product Support
• Select the Brand of your device
• Select Service Request and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

