# (Fold Inward) — — — **▶**

# (Back Cover)

# (Front Cover)

## Compliance Information

### This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Bules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery, Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosave conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C

### Rating Label Definitions

=== Direct current symbol



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

(BC) This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth

This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Southern Telecom's under Icense.

## Warranty Information

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

- To obtain warranty service:

   Visit our customer support portal: www.customersupport123.com

Warranty service not provided

This warranty obes not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of
reasonable care, unauthorized modification including software modifications such as the installation of custom firmware.

This warranty is voided in the event any unauthorized person opens, afters or repairs this product. All products being
returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OF PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OF THE PAID AND THE PROPOLOT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIFECT, INDIRECT, SPECIAL, PUNITIVE OR CONSCIUNTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS STATED HERBIN, NO OTHER WARRANTES ISHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTIOS SHALL, NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SUCH BY OUTSTRIBUTIOS SHALL, NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SUCH BY OUTSTRIBUTIOS SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SUCH BY SHATEMED ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR. IP Holdings.

PLR IP Holdings, LLC does not manufacture this product or provide any manufacturer's warranty or support.

# **Polaroid**





Made in China

# **Polaroid**

Instruction Manual

**Rugged Wireless Speaker** 



## Before You Begin...

## Customer Support

For any questions or problems with your product, please visit our website at customersupport123.com and click on the Brand of your item.



### READ CAREFULLY AND KEEP THIS MANUAL

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames,
- humid, or wet conditions. • Do not submerge in water
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.

   If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

  • This device contains a built-in battery, and should not be disposed of with regular
- household waste. Please consult the local authorities on the correct way to dispose of this device.

## In the Box

- PBT7078 Wireless Speaker (x1)
- MIcro-USB Charging Cable (x1)

# Location of Controls [賞] Button Cycle through light modes LED Indicator 3.5 mm Auxiliary [Power] Switch Charging Input Port (0) $\bigcirc$ DC 5V Ö ON OFF AUX Back Panel of Speaker

## **Getting Started**

## Charging the Speaker

Plug the small connector of the supplied charging cable into the micro-USB charging port on the back of the speaker. Plug the large connector into the USB port on a computer or a **5V USB adapter** (not included) and plug into an electrical

The LED indicator will *turn RED* while charging and turn off when fully charged.

## Powering ON/OFF

- Slide the [Power] switch to the ON position to power the speaker on. When powered on, the speaker will automatically enter pairing mode and re-pair to any nearby, previously-paired devices that have Bluetooth enabled.
- Slide the [Power] switch to the OFF position to power off.

### Using the Light Modes

Press the [0] button to cycle through the light modes, and to turn the lights OFF.

For best results with reactive light modes, turn up the volume.

To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device or connected via the 3.5 mm auxiliary input port. See the Bluetooth Pairing and Connecting to the AUX Port sections of this manual for detailed

All playback and volume will be controlled by your connected device.

- 1. Power the speaker ON. A tone will be heard, and the LED indicator will quickly
- Set your mobile device to search for Bluetooth devices. When it appears, select PBT7078 from the list of found devices.
- Once successfully paired, a tone will be heard and the LED indicator will slowly flash BLUE.

### Connecting to the AUX Port

Plug one connector of a 3.5 mm auxiliary audio cable (not included) into the 3.5 mm auxiliary input port on the speaker. Plug the other connector into the headphone jack or 3.5 mm audio output on your media-playing device.