(Fold Inward) — — — **▶**

(Back Cover)

(Front Cover)

Compliance Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Bules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery, Do not damage, open, or dismantle the battery and do not use it in
damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and
never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C
(140°F).

Rating Label Definitions

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



BC This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered tradema by Bluetooth SIG, Inc., used under license.

Warranty Information

90-day Limited Warranty Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

- Visit our website at www.southerntelecom.com
 Click on Product Support
 Select the Brand of your device
 Select the Brand of select service Request and fill out the form to begin your inquiry

Warranty service not provided

This warranty obes not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FINNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR PURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY OF PERIOD STATED ABOVE. AND OTHER EXPRESS WARRANTY OR GUARANTY GENE MY SAMY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT WILL DISTRIBUTOR SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF TOO FOR LOSS OF PROFITS, BUSINESS, SAMINGS, DATA OR RECORDS! CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS TATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTHINISTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPRIET SOLE DAY.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLB. IP Holdings.

PLR IP Holdings, LLC does not manufacture this product or provide any manufacturer's warranty or support.







Printed in China

Getting Started

Polaroid

Wireless Fabric Speaker PBT9521



Before You Begin...

Customer Support

For any questions or problems with your product, please visit our website at **SouthernTelecom.com** and click on **Product Support.**


READ CAREFULLY AND KEEPTHIS MANUAL FOR FUTURE REFERENCE.

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, numid or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion. Do not overcharge battery.If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

In the Box

- PBT9521 Wireless Speaker (x1)
- USB Charging Cable (x1)

Location of Controls



Charging the Speaker Plug the small connector of the supplied USB charging cable to the charging port on the speaker's control panel. Plug the large connector into the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into an electrical outlet.

The charging LED indicator will turn RED while charging and turn OFF when fully charged. When low on power, a tone will be heard, indicating that the speaker should be charged.

Powering ON/OFF

Make sure the speaker is charged before using for the first time.

- Move the [Power] switch to the On position to power the speaker ON. A tone will be heard and the speaker will enter Bluetooth pairing mode. The speaker will automatically re-pair to any nearby, previously-paired device.
- Move the [Power] switch to the Off position to power the speaker OFF.

Playing Music

To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device. If you are pairing for the first time, see the Bluetooth Pairing section

- 1. Power the speaker ON. A tone will be heard and the Bluetooth LED indicator will quickly flash BLUE.
- 2. Set your mobile device to search for Bluetooth devices. When it appears, select PBT9521 from the list of found devices.
- 3. Once successfully paired, a tone will be heard and the Bluetooth LED indicator

Once paired, you can adjust media playback and volume with the controls on your paired device, or with the buttons on the top of the speaker.

• Press the [▶] button to start or resume playback.

- Press the [O] button to pause playback.
 Press the [+] and [-] buttons to skip tracks.
- Press and hold the [+] and [-] buttons to adjust volume.

