(Fold Inward) - - - - **▶**

(Back Cover)

(Front Cover)

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reported or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-on Battery Inside
This product is fitted with a Li-ion battery, Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.



This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-day Limited Warranty Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product fincluding any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmentship ("Warranty") as follows:

- To obtain warranty service:

 Visit our website at www.southerntelecom.com

 Click on *Product Support* Select the *Brand* of your device

 Select Service Request and fill out the form to begin your inquiry

Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE SHALL APPLY, DISTRIBUTIOR PIGHTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY OF PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY (GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LABLE FOR ANY INCIDENTAL, DIRECT, DISCRECIAL, PUNITIVE OR CONSCIOUNTAL DAMAGES SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAWINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS STATED HERBIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPROJECT SOLD BY DISTRIBUTOR.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific le rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR, IP Holdings, LLC, used under license.

PLR IP Holdings. LLC does not manufacture this product or provide any manufacturer's warranty or support

www.polaroid.com @2020 All rights reserved

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.





Designed in US Printed in China

Getting Started

Polaroid

Instruction Manual

Active Pro Wireless Earbuds

PBTE103



Before You Begin...

READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE



To ensure safe and proper use, read all safety information before using the device. Only use with

- manufacturer-approved batteries, chargers, accessories, and supplies.
 THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
 Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.

authorities on the correct way to dispose of this device.


- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
 Do not submerge in water.
 Low power may cause poor Bluetooth connection or sound distortion.
 Do not overcharge battery.
 If using with a USB adapter, make sure the adapter is not damaged.
 Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, • The earbuds should not be disposed of with regular household waste. Please consult the local

Customer Support

For any questions or problems with your product, please visit our website at **SouthernTelecom.com** and click on **Product Support**.


- PBTE103 Wireless Earbuds (x1)
- USB Charging Cable (x1)User Manual (x1)

Location of Controls



Charging the Earbuds

Insert the small connector of the supplied micro-USB charging cable into the micro-USB charging port on earbuds. Insert the large connector into the USB port on a computer or into a 5V USB adapter (not included) and plug into a wall socket.



The LED indicator will turn RED while charging and turn OFF when fully charged. On low battery, a tone will be heard indicating that the earbuds need to be

Powering ON/OFF

- Press and hold the [(b)] button on the earbuds to power them ON and OFF. When powered ON, the earbuds will enter Bluetooth pairing mode and will automatically re-pair to an available previously-paired device in range.

Bluetooth Pairing

In order to listen to music or use the phone functions on your earbuds, you must connect to a Bluetooth device.

- 1. Power the earbuds ON, A voice will be heard, and the LED indicator will flash
- 2. Go to the Bluetooth menu in your device's Settings, and search for new connections. When it appears on the list of found devices, select PBTE103.
- 3. Once successfully paired, a voice will be heard and the LED indicator will turn solid BLUE.

Adjusting Volume & Playback

Volume & playback can be adjusted by your paired device, or with the on-ear controls below

- Press the [🖒] button to pause and resume playback.
- Press the [+] and [-] buttons to skip tracks.
 Press and hold the [+] and [-] buttons to adjust volume.

Using the Phone Functions

When connected to a Bluetooth device, you can use phone functions through the earbuds with the controls on your paired device or the on-ear controls below.

- Press the [(b)] button to answer an incoming call. Press again to hang up.
- 2x Press the [ტ] button to redial the last outgoing number.