(Fold Inward) - - - - **▶**

(Back Cover)

(Front Cover)

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to adio communications, However, there is no guarantee that interference will not occur in a particular installation. If his equipment does cause harmful interference to adio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- or summy are equal measures:

 Reprient or relocate the receiving antenna.

 Reprient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio(7)* technican for help.

 This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation,

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery, Do not damage, open, or dismantle the batt.

Just it in damp and/or corrosive conditions, Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures, Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label Definitions — Direct current symbol.

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

(BC) This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology, the Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SlG, Inc. used under license.

This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an orized retailler is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in mate and workmanship ("Warranty") as follows:

To obtain warranty service: • Visit our website at www.southerntelecom.com • Click on Product Support • Select the Brand of your device • Select the Service Request and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a dain with the carries.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, afters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSIV DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR PURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR LUXRANTY GUNEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE. AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, DOES COLLA, DUNITIVE OR CONSCIOUNTIAL DIAMAGES SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAMINGS, DATA OR RECORDS CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HERBIN, NO OTHER WARRANTIES SHALL APPLY, NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPROCEST SOLE BY SITTIBUTOR. THIS WARRANTY SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPROCEST SOLE BY SITTIBUTOR. THIS WARRANTY SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPROCEST SOLE BY SITTIBUTOR. THIS WARRANTY SHALL NOT EXCEED THE PURCHASE PRICE OF THE PROPROCESTORY.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that very from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR, IP Holdings, LLC, used under license. PLR IP Holdings, LLC does not manufacture this product or provide any manufacturer's warrant

www.polaroid.com @ 2019 All rights reserved

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Printed in China

Getting Started





Instruction Manual

True Wireless Earbuds PTBT50



Before You Begin...

Customer Support

For any questions or problems with your product, please visit our website at SouthernTelecom.com and click on Product Support.



To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

• THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with

- . Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.

• Do not submerge in water.

- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
 If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

In the Box

- PTBT50 True Wireless Earbuds (x1)
- Charging Case (x1)USB Charging Cable (x1)

Location of Controls Earbud LED [Multi] Button: Press + Hold (3s): Power ON Press + Hold (4s): Power OFF Press + Hold (2s): Activate Microphone | Charging Port

Charging the Case

The Qi-enabled charging case can either be charged directly using the included charging cable, or wirelessly with a **Qi wireless charging pad** (not included). The case is charged wirelessly through the back. Follow the charging pad manufacturer's instructions to charge.

To charge the case directly, insert the small connector of the supplied USB charging cable into the port on the bottom of the charging case. Insert the large connector into the USB port on a computer, a USB charging device, or 5V USB adapter (not included) and plug into a wall socket.

The LED indicator on the bottom of the case will flash BLUE while charging, and turn solid BLUE when the case is fully charged.

Charging the Earbuds

Open the lid of the charging case and insert the earbuds into the case's earbud charging ports. The earbuds will automatically begin charging. The earbuds' LED indicators will **turn solid RED** and the LED indicator on the bottom of the case will **turn solid BLUE** when the earbuds are charging. When the earbuds are fully charged, the case's LED indicator will turn OFF and the earbuds' LED indicators will turn BLUE for 30 seconds before turning OFF.

NOTE: When the earbuds have less than 5% charge remaining, a voice will be heard and the earbud LED indicators will **flash RED** every 10 seconds.

Powering ON/OFF

The earbuds will automatically power ON when removed from their charging case and power OFF when inserted into the case. When inserted, the earbuds will natically power off and begin charging, and the earbuds' LED indicators will

You can also power the earbuds ON/OFF manually by **pressing and holding** the

• Press and hold the earbuds' [Multi] buttons for 3 seconds to power them ON. • Press and hold the earbuds' [Multi] buttons for 4 seconds to power them OFF.

Note: The earbuds will automatically power OFF after 5 minutes if they are not paired to a Bluetooth device. The LED indicators will flash blue and red once.

Pairing the Earbuds

- 1. Power both earbuds ON at the same time. Hold them close together as shown at right. Both earbuds' LED indicators will flash RED and BLUE.
- 2. After a moment, a voice will be heard, indicating that the 2 earbuds have paired to each other 3. Set your Bluetooth-enabled device to search for Bluetooth devices. Select PTBT50 when it appears on

 Output

 Description:
- 4. Once successfully paired to your device, a voice will be heard. The earbuds' LED indicators will briefly flash RED and BLUE and then

Adjusting Playback

Once you have paired to the earbuds, you can adjust playback and volume with the controls on your paired device, or with the earbud controls below.
• Press either [Multi] button to pause. Press again to resume.

- 2x press the left earbud's [Multi] button to skip to the previous track.
- 2x press the **right** earbud's **[Multi]** button to skip to the next track.
- Press and hold either [Multi] button for 2 seconds to activate your device's voice

You must be paired to a Bluetooth device to listen to music and use the earbuds' phone functions. Consult the Pairing the Earbuds section of this user manual for

- Press either [Multi] button to answer an incoming call.
- Press either [Multi] button again to end the call.
- Triple press either [Multi] button to redial the last outgoing or incoming phone
- Press and hold either [Multi] button for 1 second to reject an incoming call.