

# Polaroid



**PTWS22**

Pro Sound True Wireless Earbuds

**User Manual**

# Before You Begin...

## READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE

### Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- **Do not submerge in water.**
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- Store only safe, dry location, away from sources of water, light, heat, and dust. The device is best stored in an airtight box or bag (not included).
- Clean by wiping with a clean dry microfiber cloth ONLY. Do not clean with water or any sort of cleaning liquid or detergent.
- The earbuds and case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

### Customer Support

For any questions or problems with your product, please visit our website at **customersupport123.com**.

### In the Box


- PTWS22 - **True Wireless Earbuds** (x1)
- Charging Case (x1)
- USB Type-C Charging Cable (x1)
- Instruction Manual (x1)

# Location of Controls

## Earbuds


### [Multi] Button

- Power On/Off
- Pause/Resume Playback
- Skip to Next Track
- Answer/End Phone Calls
- Reject Phone Calls



## Charging Case

Case  
Opening



*(Right Side  
of Case)*


USB Type-C  
Charging Port

# Getting Started

## Charging the Case

Insert the small connector of the supplied charging cable into the charging port on the charging case. Insert the large connector into a USB power source, such as the USB port on a computer, or a **5V USB wall adapter** (not included).


The LED indicators inside the case will indicate the current battery level as the case charges. All 4 LEDs will be lit when the case is fully charged.



## Charging the Earbuds

Use the included charging case to protect and charge your earbuds.

1. Charge up the case, or leave connected to power.
2. Open the lid of the charging case, and place the earbuds into the correct earbud charging ports, as shown below.
3. The earbuds' LED indicators will turn solid RED while they are charging, and turn OFF when they are fully charged.



## Powering On/Off

- Remove the earbuds from the case to automatically power them ON. The earbuds' LED indicators will **flash RED and BLUE**. When both earbuds are powered ON at the same time they will automatically pair to each other after a few seconds, and a voice will be heard indicating that they are connected.
- Insert the earbuds into the case to automatically power them OFF.
- The earbuds can also be powered ON and OFF by *touching + holding* the earbuds' **[Multi]** buttons for **3 seconds** (power ON) or **5 seconds** (power OFF). The earbuds' LED indicators will **flash RED 3 times** when they are powered OFF.

**Remove from case to power ON.**



**Note:** The earbuds will automatically power OFF if they are not paired to a Bluetooth device after 2 minutes, or if the paired device is out of Bluetooth range (10 m / 30 ft) for 2 minutes.

**Note:** Either earbud can be used independently.


## Playing Audio & Taking Calls

To use your true wireless earbuds, they must be charged up and paired to your Bluetooth-enabled device. If you are Bluetooth pairing for the first time, see the **Bluetooth Pairing** section on the next page for instruction.

Once paired, playback, volume and phone functions can be controlled by your paired device or with the controls on the earbuds listed in the **Controlling Playback, Adjusting Volume** and **Phone Calls** sections later in this manual.

## Bluetooth Pairing

1. Power the earbuds ON at the same time. The LED indicators on both earbuds will **flash RED and BLUE**. After a few seconds, a voice should be heard, indicating that the earbuds have connected to each other. **If the earbuds don't connect to each other, see the troubleshooting section at the bottom of this page.**
2. Open your device's Bluetooth menu and select **PTWS22** when it appears.
3. Another voice will be heard, indicating that the earbuds are successfully connected to your device. The LED indicators on the earbuds will turn OFF.



**Trouble Pairing the Earbuds to Each Other?** Try placing the earbuds back into their charging case, and then removing them again at the same time. They should automatically connect to each other.

**Instructions continued on the next page.**

## Controlling Playback

- Press the **[Multi]** button on either earbud to pause and resume audio playback.
- **Press + hold (2s)** the **[Multi]** button on the **left** earbud to skip to the **previous** track.
- **Press + hold (2s)** the **[Multi]** button on the **right** earbud to skip to the **next** track.

## Adjusting the Volume

- **2x Press** the **[Multi]** button on the **left** earbud to skip to **increase** volume.
- **2x Press** the **[Multi]** button on the **right** earbud to skip to **decrease** volume.


## Phone Calls

- Press the **[Multi]** button on either earbud to **answer** an incoming phone call. Press again to **end** the phone call.
- **2x Press** the **[Multi]** button on either earbud to reject an incoming phone call.

## Activating Voice Assistant

If you have a voice assistant on your paired device, you can activate it using the controls on the earbuds or the controls on your device.

- **3x press** either earbud's **[Multi]** button to **activate** the voice assistant.
- **3x press** either earbud's **[Multi]** button to **close** the voice assistant.



### **[Multi] Button:**

- 1x Press:** Pause/resume
- 1x Press:** Answer/end call
- 2x Press:** Reject incoming call
- 2x Press (L):** Increase volume
- 2x Press (R):** Decrease volume
- Press + hold (2s) (L):** Previous track
- Press + hold (2s) (R):** Next track
- 3x Press:** Wake voice assistant

# Compliance Information

## FCC Information

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



## Rating Label Definitions



Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



This symbol signifies that this is a wireless device powered by Bluetooth® technology.



This symbol represents FCC Declaration of Conformity and compliance.



# Warranty Information

## 90-Day Limited Warranty

Territory: United States/Canada

### LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

#### To obtain warranty service:

- Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com)
- Select the brand and model of your device
- Select "Service Request" and fill out the form to begin your inquiry
- Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

#### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

Printed in China  
v1. 07-2021

# Polaroid



**Have questions? We've got answers.**

Visit us at [customersupport123.com](https://customersupport123.com)



Instantly recognizable. Instantly reassuring. The Polaroid Classic Border and Polaroid Color Spectrum logos let you know you've purchased a product that exemplifies the best qualities of our brand and that contribute to our rich heritage of quality and innovation.

©2021. All rights reserved.

Polaroid, Polaroid Color Spectrum and Polaroid Classic Border Logo are trademarks of PLR IP Holdings, LLC, used under license. PLR IP Holdings LLC, does not manufacture this product or provide any manufacturer's warranty or support.