User Manual
PBT9536

(Fold Inward) – – – –▶

(Back Cover)

(Front Cover)

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label Definitions

⎓ Direct current symbol.

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.

This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

90-day Limited Warranty
Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:
- Visit our website at **www.southerntelecom.com**
- Click on ***Product Support***
- Select the ***Brand*** of your device
- Select ***Service Request*** and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

Polaroid, Polaroid & Pixel, Polaroid Color Spectrum, and Polaroid Classic Border Logo are trademarks of PLR IP Holdings, LLC, used under license.

PLR IP Holdings, LLC does not manufacture this product or provide any manufacturer's warranty or support.

www.polaroid.com ©2020 All rights reserved

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

RECYCLE
RBRC
Li-ion
1.800.822.8837

Instantly recognizable, Instantly reassuring, The Polaroid Classic Border and Polaroid Color Spectrum logos let you know you've purchased a product that exemplifies the best qualities of our brand and that contribute to our rich heritage of quality and innovation.

Designed in US
Printed in China
v1. 04-2020

Polaroid

Instruction Manual

Outdoor Wireless Boombox

PBT9536

Before You Begin...

Customer Support
For any questions or problems with your product, please visit our website at **SouthernTelecom.com** and click on **Product Support**.

Caution
READ CAREFULLY AND KEEP THIS MANUAL
- **THIS IS NOT A TOY**, please keep away from children
- Do NOT submerge in water
- Do not open this product or attempt to repair the unit yourself should it not be working.
- Low power may cause poor Bluetooth connection or sound distortion
- Do not overcharge the battery

This speaker has an Ingress Protection Rating of IPX5. This means it is protected from splashes and jets of water in any direction, but CANNOT under any circumstances be submerged in water.

The protective rubber seal must *completely cover* the speaker's input panel to protect it from *water damage*.

In the Box
- PBT9536 - **Wireless Speaker** (x1)
- USB Charging Cable (x1)
- User Manual (x1)

Location of Controls



Getting Started

Charging the Speaker
Undo the rubber protective seal and insert the small connector of the included USB charging cable into the USB charging port on the speaker. Insert the other end into a USB power port or into a **5V USB adapter** *(not included)* and plug into an electrical outlet.

The Charging LED Indicator will ***turn RED*** while charging and turn off when fully charged. When done charging, make sure the protective cover is completely sealed.

Powering ON/OFF
- Turn the **[Power]** dial to the right until it clicks to turn the speaker ON.
- Turn to the left until it clicks to turn speaker OFF.

Using the Light Modes
- Press the **[LED]** button to cycle through the light modes.

Changing Input Modes
- Press the **[M]** button to change between Bluetooth and AUX input.

Note: The speaker will automatically switch to AUX mode when a cable is plugged into the AUX input port.

Playing Music
To enjoy music on your speaker, make sure that the speaker is properly paired to your Bluetooth-enabled device or connected via the 3.5 mm AUX input.

See the **Bluetooth Pairing** and **Using with a Wired Device** sections for detailed instructions.

Bluetooth Pairing
1. Power the speaker ON. A tone will be heard and the LED indicator will ***quickly flash BLUE***.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **PBT9536** from the list of found devices.
3. After a successful pairing, a tone will be heard and the Bluetooth LED indicator will ***turn solid BLUE***.

Press and hold the **[⏯]** button to instantly disconnect any paired devices.

Controlling Playback & Volume
- Press the **[⏯]** button to pause/resume media playback.
- Press the **[⏮]** and **[⏭]** buttons to skip tracks.
- Use the **[Power]** dial to adjust speaker volume.

Using the AUX Port
Plug one connector of a 3.5 mm audio cable *(not included)* into the 3.5 mm AUX input on the speaker. Plug the other connector into the headphone jack or audio output port of your media-playing device.

All playback will be controlled by your connected device.

Using the Microphone Input
To use the speaker's microphone input, plug the 1/4" connector of a wired microphone or microphone cable *(neither included)* into the microphone input.
- Turn the **[Mic Vol]** dial to adjust microphone volume.